

# DAC-42(A)



DIGITAL AMPLIFIER AND CONTROLLER CARD FOR ALL KIND OF PROPORTIONAL VALVES

Applicable for SW Versions:	Model Code	SW Version	Remarks
	DAC-42(A)-x-PN-x Operation Mode: 01, 02, 03, 04, 06, 08, 10, 11	V 11.xx	xx = 01 or higher * = a, b, .... x = additional options



HCS Hydraulic Control Systems GmbH  
Neuffener Str. 29  
D-72636 Frickenhausen  
Germany  
Telefon: (+49) 7025 - 911 007  
Telefax: (+49) 7025 - 911 008  
Email: info@h-c-s-gmbh.de

## Revision History

Revision	Date	Author	Description
R 1.0	22.01.2024	Bm	First edition

## Table of Contents

<b>1</b>	<b>Abbreviations .....</b>	<b>4</b>
<b>2</b>	<b>Terms and Definitions .....</b>	<b>4</b>
<b>3</b>	<b>General information .....</b>	<b>5</b>
3.1	Abstract .....	5
3.2	Scope .....	5
3.2.1	Copyright .....	6
3.2.2	Documents place of storage .....	6
3.2.3	Warning signs, symbols and notes .....	6
3.2.4	Safety and liability .....	7
3.2.5	General information .....	8
3.3	Terms and conditions .....	9
3.4	Delivery state (default setting) .....	9
3.5	Correct product use .....	9
3.6	Non-intended product use .....	9
3.7	Selection and qualification of personnel .....	10
3.7.1	Inquiries and ordering .....	10
3.7.2	Service and repair .....	10
3.7.3	Cleaning, storage, transport .....	11
3.7.4	Delivery state (default setting) .....	11
3.8	Introduction .....	11
3.9	General Applications .....	11
<b>4</b>	<b>Product overview and description .....</b>	<b>12</b>
4.1	Technical features .....	12
4.2	Technical data .....	13
4.2.1	General technical data .....	13
4.2.2	Technical data for optional bus interfaces .....	14
4.2.3	Block diagram hardware .....	14
4.3	Model code .....	15
<b>5</b>	<b>Installation .....</b>	<b>16</b>
5.1	Mounting .....	16
5.2	Connection .....	17
5.2.1	General recommendations .....	17
5.2.2	Wires and preparation .....	17
5.2.3	EMC .....	18
5.2.4	Specific recommendations for wiring and control cabinets .....	18
5.3	Terminal assignment .....	22
5.4	Picture of rear connector .....	22
5.5	Operation modes .....	23
5.6	Wiring diagrams for all operation modes .....	24
5.6.1	Wiring diagram for operation mode 01 .....	24
5.6.2	Wiring diagram for operation mode 02 .....	25
5.6.3	Wiring diagram for operation mode 03 .....	26
5.6.4	Wiring diagram for operation mode 04 .....	27
5.6.5	Wiring diagram for operation mode 06 .....	28
5.6.6	Wiring diagram for operation mode 08 .....	29
5.6.7	Wiring diagram for operation mode 10 .....	30
5.6.8	Wiring diagram for operation mode 11 .....	31
<b>6</b>	<b>Commissioning .....</b>	<b>32</b>
6.1	Front elements .....	32
6.1.1	DAC-42(A)-x-PN .....	32
6.2	Software block diagrams .....	33
6.2.1	Operation Mode 01; 1 valve with 2 solenoids, open loop .....	33
6.2.2	Operation Mode 02; 2 valves with 1 solenoid each, open loop .....	34
6.2.3	Operation Mode 03; 1 valve with 2 solenoids and spool position feedback .....	35
6.2.4	Operation Mode 04; 1 valve with 2 solenoids and process value feedback .....	36
6.2.5	Operation Mode 06; 1 valve with 2 solenoids spool position feedback and process value feedback .....	37
6.2.6	Operation Mode 08; 2 valves with 1 solenoid and process value feedback .....	38
6.2.7	Operation Mode 10; stand-alone controller with process feedback .....	39
6.2.8	Operation Mode 11; stand-alone controller with two process feedbacks .....	40

<b>7</b>	<b>General communication information.....</b>	<b>41</b>
7.1	Special information for bus activation .....	41
7.2	General information about TADR (Telegram Address) .....	41
7.3	General information about CMD (Command) and SADR (Slave Address) .....	41
<b>8</b>	<b>Simple commands .....</b>	<b>42</b>
8.1	CMD 3 Master Read .....	42
8.1.1	CMD = 3, Master Read parameters (7 bytes) .....	42
8.1.2	CMD = 3, Response from Slave (4 + CNT bytes) .....	42
8.1.3	CMD = 3, Error from DAC-4x(A) (4 bytes).....	43
8.2	Telegram example CMD = 3 .....	43
8.3	CMD = 6, Master Write .....	44
8.3.1	CMD = 6, Master Write single parameter (7 bytes) .....	44
8.3.2	CMD = 6, Response from DAC-4x(A) (7 bytes) .....	44
8.3.3	CMD = 6, Error from DAC-4x(A) (4 bytes).....	45
8.4	Telegram example CMD = 6 .....	45
8.4.1	Example, write parameter .....	45
8.4.2	Example, write set value .....	46
<b>9</b>	<b>Complex commands .....</b>	<b>47</b>
9.1	CMD = 15, Master writes multiple parameters (8 bytes) .....	47
9.2	CMD = 15, Response from DAC-4x(A) (9 bytes) .....	47
9.3	CMD = 15, Error from DAC-4x(A) (4 bytes) .....	48
9.4	Examples, CMD = 15, single slave, DAC-4x(A) .....	48
9.5	CMD = 15, structure of Profinet telegram definition, depending on SW Versions .....	49
9.5.1	General .....	49
9.5.2	Version for Mode 1 (open loop, one valve with two solenoids) .....	51
9.5.3	Version for Mode 2 (open loop, two valves with one solenoid each).....	52
9.5.4	Version for Mode 3, 4, 10 (closed loop) .....	53
9.5.5	Version for Mode 6, 11 (two closed loops) .....	54
9.5.6	Version for Mode 8 (closed loop) .....	55
<b>10</b>	<b>Configuration for SIEMENS TIA portal .....</b>	<b>56</b>
10.1	Setup the network configuration for the DAC-4x(A) .....	56
10.2	Assign the IO-Module from the GSD to the device .....	56
10.3	Install the function block.....	57
10.4	Explanation of the function block .....	58
10.4.1	General .....	58
10.4.2	Classic CPU 300,400: Definition of the data buffer address .....	59
10.4.3	CPU 1200,1500: Specification of the data buffer address based on the hardware identifier.....	60
10.4.4	CMD 3, Reading values from one DAC-4x(A) node .....	61
10.4.5	CMD 6, Writing parameters the DAC-4x(A) .....	62
10.4.6	CMD 15, Writing and Reading once the connected DAC-4x(A) .....	63
<b>11</b>	<b>List of parameters .....</b>	<b>64</b>
<b>12</b>	<b>Declaration of Conformity .....</b>	<b>70</b>

## 1 Abbreviations

Abbreviation	Description
DAC	<b>D</b> igital <b>A</b> mplifier and <b>C</b> ontroller
EMC	<b>E</b> lectro <b>M</b> agnetic <b>C</b> ompatibility; properties of the unit in order to comply with the EMC directive
USB	<b>U</b> niversal <b>S</b> erial <b>B</b> us; interface for communication between a PC and the DAC-4x(A)
PC	<b>P</b> ersonal <b>C</b> omputer
μC	<b>M</b> icro <b>C</b> ontroller; CPU used inside the unit to control all functions
mamsl	<b>m</b> eters <b>a</b> bove <b>m</b> edian <b>s</b> ea <b>l</b> evel
IP65	Protection Class; solid particle protection and protection level against water ingress
LED	<b>L</b> ight <b>E</b> mitting <b>D</b> iode
PWM	<b>P</b> ulse <b>W</b> idth <b>M</b> odulation; method to control the output current at low power losses
Ub	Supply voltage
FS	<b>F</b> ull <b>S</b> cale

Table 1: Abbreviations

## 2 Terms and Definitions

Term	Description
Amplifier Card	Amplifier for 19" rack system in Eurocard format
HCSTool	Software tool provided by HCS in order to adjust and parametrize DAC-4x(A) units
CANopen	Bus interface for digital communication, defined by CIA
PROFIBUS	Process Field Bus interface for digital communication, defined by BMBF (German department of education and research) and used by Siemens
PROFINET	Process Field Net interface for digital communication, the standard is maintained and supported by PROFIBUS & PROFINET International
ETHERNET/IP	(IP = Industrial Protocol) is an industrial network protocol that adapts the Common Industrial Protocol to standard Ethernet
USB-C connector	Connector type used on the USB interface

Table 2: Terms and definitions



## 3 General information

### 3.1 Abstract

This document describes the function of the HCS digital amplifier and controller card "DAC-4x(A)".

This manual was prepared with great care and the contents reflect the author's best knowledge. However, the possibility of error remains and improvements are possible. Please feel free to submit any comments regarding errors or possibly incomplete information to HCS GmbH.



## DANGER

**Read this manual carefully before working with the digital amplifier cards!**

**The general and especially the safety instructions of this manual have to be observed in any case!**

**Electronic equipment of all kind can have component failures or software may lead to unpredictable reactions. Secondary safety measures must be taken in order to ensure safety under all circumstances. This is especially the case for safety critical applications.**

**Furthermore, it is the responsibility of the user to always comply with applicable safety standards (e.g. EN 13849) and to implement a system architecture capable to cover all safety requirements. The unit itself does not comply with any performance level given in EN 13849 or any SIL level as per EN 61508.**

**Applicable laws and safety standards have to be observed at any time. Before commissioning or using the equipment the necessary risk analysis must be conducted and suitable protection measures must be taken.**

**HCS GmbH refuses any liability in case of omission to comply with these requirements.**

### 3.2 Scope

With the help of this document a professional, competent and trained user should be able to install, wire, connect, commission, set parameters, perform fault analysis and fix issues. Also, the document will provide the user any technical and operational details necessary to safely operate the product. It remains the user's responsibility to set-up a safe working environment while operating the product.

The information contained in this manual is valid at the time of this version's release. See footer for version number and release date of this manual.

## 3.2.1 Copyright

© All rights reserved. Except for the usual review purposes, no part of this work may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information retrieval system, without the written permission of **HCS HYDRAULIC CONTROL SYSTEMS GmbH** (following referred to as HCS).

## 3.2.2 Documents place of storage

This manual and all other associated documentation for hardware and software must always be kept in a location where they will be readily accessible and close to the digital amplifier and controller card DAC-4x(A) or the equipment in which it is installed.

## 3.2.3 Warning signs, symbols and notes



### DANGER

Identifies safety instructions that are intended to warn of an immediate and impending danger to life and limb. Failure to observe these safety instructions will – with a very high probability - lead to death, serious personal injury (disablement)!



### WARNING

Identifies safety instructions that are intended to warn of potential danger to life and limb. Failure to observe these safety instructions might lead to death, serious personal injury (disablement)!



### CAUTION

Identifies safety instructions that are intended to warn of slight personal injury. Failure to observe these safety instructions might lead to slight personal injury.

### NOTICE

Failure to observe this safety notice can result in property damage!



Identifiers important information

Other identifiers (when applicable):

Identifier	Description
•/ -	Listings
□	References to another chapter, page, table or figure in this manual
blue text	Hyperlink within the document
1., 2., ...	Steps in a procedure that should be performed in consecutive order
«ER»	LEDs of the amplifier (for example, «ER»
< >	parameter name
[xx]	Pin number of the rear connector
"..."	Used for references

Table 3: Identifiers

### 3.2.4 Safety and liability

#### NOTICE

The information in this document is subject to change without further notice. HCS assumes no responsibility for any faults that may appear in this manual.

This operating manual represents the knowledge of HCS and during the drafting of this operating manual the greatest possible care was taken. Nevertheless, HCS disclaims any responsibility and liability claims for individual applications of the user. This is particularly true in cases of non-compliance, omissions, faults, misinterpretations and misunderstandings.

Applicable laws and safety standards have to be observed at any time. Before commissioning or using the equipment, the necessary risk analysis must be conducted and suitable protection measures must be taken.

This manual only describes the functionality and influence of the parameters. The described software functionality can be used in various amplifier models which can be implemented in a vast range of applications. Hence it is not possible to assume liability for the influence of the parameters.

HCS GmbH refuses any liability in case of omission to comply with these requirements.

#### WARNING

In the case of applications with critical safety requirements or where accident prevention regulations must be observed, it may be necessary to isolate the components from the solenoids with relays in e-stop circuits.

To switch off the enable signal (0 V at terminal 8d) is insufficient. In these cases, hydraulic and/or mechanical safety measures to stop the drive must be provided (e.g. through switching valves with position monitoring).

## WARNING

All types of proportional directional valves, which may be used in all kinds of different environments and applications, can eventually fail and hence are able to cause damage.

It is the customers obligation to analyze all safety related aspects of the application. It is within the full responsibility of the machine builder and/or system integrator to make the final selection of products and reassure and confirm that all requirements regarding safety and performance are met.

The procedure of selecting the proper control system and related safety levels is covered by the machine directive EN 13849.

## NOTICE

**Liability for any content of this document is rejected!**

Any claims against HCS GmbH – based on whatever legal reason – resulting from the use of the information, programs, engineering and performance data etc., described in this document shall be excluded. Exclusion in such cases shall not apply for mandatory liability, e.g. under the “Product Liability Act”, in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition. Damages for breach of a substantial contractual obligation are, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change of the burden of proof to your detriment.

We reserve the right to make changes to this document at any time without prior notice.

### 3.2.5 General information

## WARNING

ESD (electrostatic discharge) may damage components on the card. In order to prevent any damage please always follow the recommendations below!

Discharge static voltage from your body by using best practice.  
Work in safe environment and do not use any devices in the working surrounding which could generate or hold static charge. Avoid using the product in areas where floors or surfaces are composed of materials that could generate static charges.

Handle all equipment very carefully and do not touch exposed pins or components.

Store and transport the units only in its original packaging.



## WARNING

**During commissioning, particular attention must be paid to the correct design and realization of the wiring. This must be checked before applying the supply voltage.**

**To avoid collisions, the safety devices and limit switches must be activated. All safety regulations are to be observed.**

**Monitoring the fault signal (terminal 14d) is recommended.**

### **Malfunctions can occur with the following:**

- Changes to the settings made by the supplier.
- Neglecting of operating parameters (e.g. supply voltage, application of inadmissible signals on inputs or outputs, ambient conditions, wiring, unsafe loads such as motors, contactors, relays, ohm loads, etc.)
- Faults in series-connected controls components and set points or actual values
- Faults in the subsequent hydraulic components
- Removing of solenoids connections.

### **3.3 Terms and conditions**

Please pay attention to our general terms and conditions (available on request).

### **3.4 Delivery state (default setting)**

The product is shipped in a ready-to-use state (default settings). After correct installation and setting of all parameters relevant for the application, the amplifier card is ready for use.

### **3.5 Correct product use**

The digital amplifier and controller cards “DAC-4x(A)” are used for the following applications:

- Controlling of proportional valves (namely directional control valves); with or without feedback (depending of operation mode).
- To convert set point signals into a current signal to control one proportional valve and spool position feedback in the aforementioned valves.
- For industrial applications only.

The operation of other inductive or resistive loads is not recommended (motors, heaters, etc.). If you are considering any applications like this please contact HCS GmbH.

If used correctly, the safety of the user as well as the safe and proper function of the amplifier DAC-4x(A) is given.

### **3.6 Non-intended product use**

The digital amplifier and controller cards “DAC-4x(A)” should not be used in the following cases:

- if noticeably damaged
- when the electrical connections are damaged
- if they do not function correctly
- after incorrect handling or storage
- in non-appropriate applications or environments.

In these cases, the digital amplifier and controller card must be disabled and secured against accidental restarting.

In the case of applications with critical safety requirements or where accident prevention regulations must be observed, it may be necessary to isolate the components from the solenoids with relays in e-stop circuits. In these cases, hydraulic and/or mechanical safety measures to stop the drive must be provided (e.g. through switching valves with position monitoring).

During commissioning, particular attention must be paid to the correct design and realization of the wiring. This must be checked before applying the supply voltage.

To avoid collisions, the safety devices and limit switches must be activated. All safety regulations are to be observed.

Malfunctions can occur when:

- Changes to the settings made by the supplier.
- Neglecting of operating parameters (e.g. supply voltage, application of inadmissible signals on inputs or outputs, ambient conditions, wiring, unsafe loads such as motors, contactors, relays, ohm loads, etc.)
- Faults in series-connected controls components and set points or actual values
- Faults in the subsequent hydraulic components
- Removing of valve connection.

### 3.7 Selection and qualification of personnel

Only qualified users may work with the amplifier. Qualified users are properly trained experts with the required knowledge and experience. In particular, these experts must have the authorization to bring into operation systems and power circuits in accordance with safety engineering standards. They must be familiar with safety concepts common in automation.

#### 3.7.1 Inquiries and ordering

To order the product, the complete order code is requested.

See □ Chapter "4.3 Model code", page 15

Please pay attention to our general terms and conditions (available on request) and forward orders and enquiries to the companies as listed on our web page:

## Sales Partners (h-c-s-gmbh.de)

<https://www.h-c-s-gmbh.de/en/sales-partners>

They are our official distributors/partners. We reserve the right to forward any direct inquiries or orders to our distributors/partners. Nevertheless, we will be available for any necessary technical support.

Germany and other countries without distributor/partner:

Neuffener Strasse 29  
D-72636 Frickenhausen  
Tel: (+49) 7025 - 911 007  
Fax: (+49) 7025 - 911 008  
Email: [info@h-c-s-gmbh.de](mailto:info@h-c-s-gmbh.de)  
[www.h-c-s-gmbh.de](http://www.h-c-s-gmbh.de)



#### 3.7.2 Service and repair



**Do not attempt - under any circumstances - to repair the product yourself**

After repair, certain adjustments and test procedures must be performed; this can only be made by qualified and authorized personnel. Products that need repair can be sent to the addresses:

Please enclose a detailed description of the error, malfunction or failure with the sent item and state the serial number and the purchase date. This will speed up the process and guarantees a fast and reliable repair.

In the case of a fault or a malfunction, your distributor can give you instructions on the phone or in writing before accepting a repair order. For service and repair, we offer experienced and qualified personnel. In case you need our assistance, please contact the address:

See □ Chapter "3.7.1 Inquiries and ordering", page 10

### 3.7.3 Cleaning, storage, transport

The product should only be transported and stored in the original packaging to ensure suitable protection against mechanical damage as well as electrostatic discharge.

- Keep the amplifier card away from moisture and dust
- Observe the allowed storage and transportation temperature range
- If it should be necessary to clean the amplifier, we recommend sending it back to the manufacturer or any distributor and partner:

See [□ Chapter "3.7.1 Inquiries and ordering"](#), page 10



### CAUTION

**Unpacking and handling should be left to suitably trained personnel.  
Beware of damaging the amplifier by electrostatic discharge**

### 3.7.4 Delivery state (default setting)

The product is shipped in a ready-to-use state (default settings). After correct installation and setting of all parameters relevant for the application, the digital amplifier and controller card is ready for use.

## 3.8 Introduction

The digital amplifier and controller card DAC-4x(A) features leading edge technology. This electronic device meets the industrial standards for EMC. This ensures a high interference security and low interference emission.

The performance characteristics are possible through the use of the most current microprocessor technology (32-bit floating-point CPU) combined with other state of the art components. In addition to all control functions, the microprocessor also handles closed-loop control. The system features are essentially determined by the software and provide reserve capacity for further developments and adaptations.

The following features distinguish the DAC-4x(A) series:

- Fully digitized amplifier card with the advantage of
  - no on-board potentiometer
  - no jumper settings required
  - digital setting and display of all parameters by means of PC with HCSTool
  - user safety during parameterization
- flexible and reliable system:
  - use of a modern 32-Bit floating point  $\mu$ C
  - high performance and yet power reserve
  - high reliability and safety through the use of a integrated watch-dog and reset function
  - variable settings for magnetic systems making high flexibility possible
- functional use of the interface:
  - change of selected parameters "on-the-fly" without interference or interruptions of the working cycle
  - analyzing of system performance through selection of display parameters with the PC and by using the 4-channel oscilloscope function included in HCSTool
  - bus interfaces available (PROFIBUS/PROFIDRIVE, PROFINET, ETHERNET/IP, CAN-OPEN)

## 3.9 General Applications

The amplifier card DAC-4x(A) is used for:

- With or without electrical feedback transducers
  - proportional directional valves direct and pilot operated
  - proportional flow control valves
  - proportional pressure reducing valves
  - proportional pressure regulating valves
  - cartridge valves
  - servo valves with torque motors
- Controlling of hydraulic motors, - installations and – systems, e.g.:
  - position
  - speed
  - pressure
  - revolutions per minute

- torque
- power etc.
- Volume flow control and pressure control of pumps (if the occasion arrives: power limiting function; controlling valve spool position)
- Controlling of different process values:
  - P/Q controlling
  - pump controlling
  - controlling of pressures
  - controlling of pilot- and main stage
  - cascade controlling of components etc.

## 4 Product overview and description

### 4.1 Technical features

The system features of the DAC-4x(A) are the following:

- One differential command input (set point). Range of  $0 \pm 10$  respectively 0 or 4 ... 20 mA, resolution 16-bit.
- Two single ended command point inputs. Range of  $0 \pm 10$  respectively 0 or 4 ... 20 mA, resolution 16-bit.
- Two single ended feedback inputs. For current and voltage. Wide range of adjustability, resolution 16-bit.
- Two optional inputs for LVDT signals. 1 or 2 inputs with optional extension board; information on request.
- Integrated reference voltage supply of  $\pm 10$  V (10 mA max.), to supply set point potentiometer or actual value transducer.
- 4 (optional 5) recallable digital adjustable set points.
- Direction externally set through "+" and "-" inputs.
- Enable signal for output stages.
- Reset-Ramp for fast ramp function zeroing.
- Status outputs "error" and "comparator".
- All digital inputs and outputs are optically isolated for functional security.
- Display with four 7-segment indications and six keys for easy handling and operation.
- Function indication through front panel by LEDs.
- Additional switching output (24 V, max 1A) to directly disable safety valves.
- Analog outputs to perform controller functions and / or enable subsequent electronic devices and monitoring ( $\pm 10$  V, 12-bit resolution). One is also selectable as current output 4 ...20 mA.
- Additional front panel test jacks (2 mm) for easy commissioning. Test jacks for set point (SET)\*1, for feedback 1 (FB1), for solenoid currents (A) and (B) and monitor input (MON) display for analog display of all parameters ( $\pm 10$  V, 12-bit resolution).
- USB interface with USB-C connector
- Serial interface RS232 (instead of USB\_C interface; optional on request)
- Optional available: PROFIBUS, PROFINET, ETHERNET/IP and CANopen interfaces available.



## 4.2 Technical data

### 4.2.1 General technical data


Feature	Range, characteristics
Supply voltage and Control voltage for digital inputs	12 V DC - 10 % ... 24 V DC + 20 %; residual ripple < 10 % (max. 50 VA power draw) current draw per input < 20 mA
Solenoid system selection	0.8 A; 1.1 A; 1.3 A; 1.6 A; 2.4 A; 2.7 A and 3.5 A (intermediate values adjustable) Servo valve current ranges available on request!
Ambiant operating temperature	- 40 °C to + 70 °C
Storage temperature	- 45 °C ... 85 °C
Humidity (relative air humidity)	max. 95 % non condensing
Max. elevation	2,000 m (mamsl)
Class of protection	IP20 when installed in 19" rack system
Connector	In accordance with DIN 41612, 48 pol form F gold plated
EMC	In accordance with the applicable industrial standards (CE - conformity) <sup>-3</sup>
Dimensions front panel / PCB	50,5 x 128,4 mm; 10TE / 3 HE; 100 x 160 mm euro format
Analogue set values inputs	3 inputs with 16 Bit resolution (1 x differential; 2 x single ended; 0 ... +-10 V, 0/4 ... 20 mA)
Analogue feedback U/I	2 inputs with 16 Bit resolution (current and voltage with wide range of adjustability)
Analogue feedback LVDT <sup>-2</sup>	1 or 2 inputs with optional extension board; detailed information on request
Digital inputs	8 inputs (S1.01 ... S1.04, ENABLE, RAMP 0, DIRECTION +, DIRECTION -)
Solenoid current (output)	2 PWM output stages, each for up to 3,5 A (with over-energ. and quick de-energization)
Analogue output	1 output with 12 Bit resolution, 0 ... +-10 V or 4 ... 20 mA (selectable)
Monitor output	1 output with 12 Bit resolution, 0 ... +-10 V
Digital outputs	2 outputs, voltage level 0 V / 24 V, 10 mA (ERROR, COMPARATOR)
Test jacks at front <sup>-2</sup>	Current A and B, sensor 1 (Fb1) set value (S1.06), Monitor and GND
Auxiliary reference voltage	+- 10 V, max. output 10 mA
Optional digital I/O signals	3 for variable usage, voltage level 24 V or 5 V
Interface 1	USB-C or (optional) RS232, 9-pol SUB-D-connecor at face plate
Optional interface 2 <sup>-2</sup>	PROFIBUS DP; PROFNET; other bus interfaces on request
Display and keypad <sup>-2</sup>	4-digit 7-segment display, 6 keys, status LED's
PWM frequency	22.2 kHz - independant from dither frequency (customer specific frequencies available)
Cycle times	Closed loop 1 and 2: 0.1 msec

Table 4: General Technical Data



**Detailed technical data in the “DAC-4x(A) Manual E Rxx yyyyymmdd.pdf”  
please ask HCS GmbH if needed.**

## 4.2.2 Technical data for optional bus interfaces

Feature PROFIBUS	Range, characteristics
Supply voltage	Via DAC-4(A) motherboard
Temperature ranges, EMC, Mounting/housing	Refer to page 2
PROFIBUS-DP 	<ul style="list-style-type: none"> <li>- Certified by PNO</li> <li>- Supports PROFIBUS-DP Slave in accordance with IEC 61158</li> <li>- Supports PROFIBUS DPV1</li> <li>- Maximum 244 Byte in-/output data</li> <li>- Supports up to 12 Mbaud (autodetect)</li> <li>- Electrical isolated and opto-decoupled</li> </ul>
Connection / Type of connector	RS485, Sub-D 9-pole female
Status signals	LED „Buserror“ (red): DAC-4 error LED is used
Address selection	DIP switch 1- 8, each on/off


Feature PROFINET	Range, characteristics
Supply voltage	Via DAC-4(A) motherboard
Temperature ranges, EMC, Mounting/housing	Refer to page 2
PROFINET 	<ul style="list-style-type: none"> <li>- Approved by PNO</li> <li>- Meets the standard IEC 61158 and IEC 61784</li> <li>- LAN 10/100Base-T(X)</li> <li>- 2 x RJ-45 LAN (Daisy Chain)</li> <li>- Cycling data exchange RT and IRT with PROFINET IO-Controller</li> <li>- Sending and receiving of diagnostic and process alarms</li> <li>- I&amp;M0...4-data available</li> <li>- Supporting of PROFINET naming (device name) and TCP/IP addressing</li> <li>- Fast Startup functionality supported</li> <li>- Shared Device supported</li> <li>- Media Redundancy Protocol support.</li> <li>- Electrical isolated interface</li> </ul>
Connection / Type of connector	In/Out: 2 x RJ45 (integrated switch)
Status signals	Power (green), Error (red), Maint (yellow), Sync (yellow), Status (yellow)
Future usage	DIP switch 1- 3, each on/off

Table 5: Technical Data for Optional Bus Interfaces

## 4.2.3 Block diagram hardware





Figure 1 : Block Diagram Hardware

## 4.3 Model code



### Model code examples:

Version with display for one valve with  
2.7 A solenoids closed loop operation  
in mode 3. With USB-C interface:

**DAC-44(A)-03-270-S0**

Version without display for one valve with  
0.8 A solenoids open loop operation in mode 1  
with RS232 interface and conformal coating:

**DAC-44(A)-01-080-SRS232-CC-XLT**

Figure 2 : Model code

**Remark:** Servo valve versions are covered in a separate manual



## 5 Installation

### 5.1 Mounting

- Compare card type (refer to label on rear connector) with part list / diagram.
  - The card generally could be mounted in any direction. However, it is recommended to choose a vertical orientation for better convection cooling. Also, this orientation will be obviously better suited for adjusting parameters or monitoring display values via the keypad and display (applicable for DAC-44(A) versions only).
  - The amplifier card should be mounted in a shielded environment (e.g. control cabinet).
  - The amplifier card module has to be mounted either in a rack according to the 19" rack standards (EIA 310-D, IEC 60297 und DIN 41494 SC48D).
- it is also possible to install the card either in an appropriate card holder or HCS own universal rack:



Figure 3 : Card holder and universal rack (not to scale!)

Dimensions Eurocard for 19" rack mounting:

For 3 HE: 100 mm × 160 mm, connector on small side

Faceplate dimensions DAC-4x(A): 3 HE x 10 TE (= 128,4 x 50,5 mm)




Figure 4 : General example for 19" Rack systems 3 HE

## 5.2 Connection

### 5.2.1 General recommendations

The general supply voltage for the unit is at the terminals:

[26bd] = 0 V and [32bd] = +UB is 12 V DC - 10 % ... 24 V DC + 20 %; residual ripple < 10 %  
(at supply voltage down to 12 V DC some limitations may be applicable).

Output stages are electronically protected against short circuit and overload. The amplifiers should be protected with a quick-acting fuse.

The solenoids are connected at terminals [22bdz] and [28bdz] for solenoid A; terminals [24bdz] and [30bdz] for solenoid B. The terminals [bdz] are bridged on the amplifier. We recommend using all three terminals for better load distribution.

If no electrical isolation of logic inputs or outputs is required, terminal [26bd] may be bridged to terminal 2d and terminal [32z] to terminal [32bd].

Terminal [18d] is the GND for the digital signals.



**When replacing amplifier cards model VRD350 and VRD355, please note that the connection for PE was at terminals 18bd. If PE is connected to these terminals, disconnect.**

### 5.2.2 Wires and preparation

Connection wires have to comply to the following specifications:

Feature	Required
Wire type	Hookup cable; stranded
Cross section: Solenoids and supply	min AWG 16 / 1.5 mm <sup>2</sup>
Cross section: Signal, command and sensor:	min AWG 20 / 0.5 mm <sup>2</sup>
Wire length	Max. 50 m (> 50 m consult factory)
Skinning length	7 mm
Soldering of wires	Not permitted!

Table 6: Wires recommendation



#### WARNING

**The assembly contains electronic components. Incorrect handling or operation can lead to damage through electrostatic discharge (ESD). Only trained personnel should work with the unit. All safety instructions must be observed. Damage may result if the card is disconnected while the power supply is still on. Avoid such actions under all circumstances. The information in this document is subject to change without notice.**



#### WARNING

**Avoid under all circumstances to use logical signals from the card (i.e. "Error") for switching machine safety circuits (refer also to EU standard EN13849)!**

## 5.2.3 EMC

Devices DAC-4x(A) series are class “A” equipment and therefore only suitable for industrial surroundings.

The distance between a source of interference (device emitting interference) and an interference sink (a device under the influence of interference) is very important. The greater the distance between the source of interference and the sink, the smaller the effects on the equipment will be. In other words, the closer a device is placed to the source of interference, the greater the interference amplitudes. For this reason, a minimum gap of 0.25 m should be kept between the amplifiers and strong sources of interference. The following devices are to be regarded as strong sources of interference:

- Switching power supply units
- Frequency converters
- Digital drive modules
- Mains filters with wiring (even if shielded)
- AC/DC commutator motors
- Motor cables (even if shielded)
- Switched inductances, even if anti-interference measures have been taken (solenoid valves, contactors, relays, etc.)

One of the most common input points for interference is wiring. If interfering cables are laid at least 0.25 m away from cables susceptible to interference, the influence on each other can be minimized. Parts of the amplifier wiring may be susceptible to interference (analog set point and actual value, solenoid cables). If these cables are laid parallel over a distance longer more 10 m, the necessary distance between them must be increased. Cables susceptible to interference should never be laid parallel to motor cables. The influence is the least when the cables cross particularly at an angle of 90°.

However, interference can also arise from cables in the amplifier wiring system, in particular solenoid cables. Examples of devices which are particularly susceptible to interference:

- Office PC's
- Sensors with small output voltages / currents
- Capacity proximity switches
- Audio equipment (television, hi-fi, radio, etc.)
- Devices which do not meet the EMC guidelines

## 5.2.4 Specific recommendations for wiring and control cabinets

The following rules and tips are by no means to be complete. Since various electronic components are used in a variety of different ambient conditions, these guidelines only represent a compromise. The actual design of the wiring also depends on the interference emission and interference sensitivity of each individual component.

- Use shielded and twisted-pair cables for the solenoid connections. The shield must be grounded (PE Protective Earth) at both ends. The capacity should be ca. 120 pF/m. If the cables are up 100 m long, their cross-section has to be 1.5 mm<sup>2</sup> and 2.5 mm<sup>2</sup> for cables longer than 100 m.
- Shields of digital signal lines are to be connected at both ends to a PE, a good conductivity of the connection should be provided.
- Set point and actual value connections should have shielded and twisted-pair cables. The analog signal line shields are to be connected, with low impedance, at both ends to PE
- In environments with high interference, use double shielded cables for set point and actual value connections. The inner shield is only grounded at one end, the outer at both ends.
- In the event of low-frequency interference on the analog signal lines (measured value fluctuations), the shield should be connected at one end. Preferably, use a corresponding compensation of potential (see also the following point).
- Use only cables with a Cu shielding grid and a covering of > 85 %. Avoid screening films. Metal foils must be avoided.
- The shield should not be interrupted along the entire length of the cable. If contactors, safety switches, chokes, etc. have to be used in the wiring, the installation of a metallic housing with a high HF shield may be necessary.
- Shield terminals are to be connected over a large area to the shield rail to function well.
- The shield rail must be installed close to the cable duct in the control cabinet.
- The metallic parts of the electrical cabinet are to be connected with low impedance on large areas. Make the desired connection with mechanical aids such as scratch plates if necessary. Connect the doors of the cabinet with the shortest possible homogeneous tapes (multiple).
- Solenoid valves, contactors, relays, brakes, etc. must be suppressed directly at the interference source. Suitable suppression devices are, for example, RC networks, diodes or varistors.
- Analog and digital signal lines should preferably enter the control cabinet from only one side.
- Non-shielded lines of an electric circuit must be twisted.
- Auxiliary wires are to be grounded at both ends.
- Avoid unnecessarily long lines. This keeps the coupling impedance low.
- Wiring should preferably not be freely hanging in the cabinet. Lay cables, including auxiliary cables, as close as possible to mounting plates and cabinet housing.

- In the case of a potential difference between the shield connections, a compensation conductor of  $<10 \text{ mm}^2$  should be laid parallel to the shield to reduce the transient current. A multiple connection of the shield to the cabinet casing and thus PE is generally possible. Also, a multiple connection of the shield outside the cabinet is possible.
- If filters are installed, place them close to the source of interference and keep a good surface contact to the cabinet or mounting plate.
- If converters are used, converter filters must be provided. Variable speed motors may have to be connected using shielded lines. All further instructions of the converter manufacturer have to be observed.

The following two pages show illustrations of:


- The most important types of interference and their remedies
- Construction of EMC suitable electric cabinets and systems

The diagrams have been provided by our competent partners for all questions regarding EMC:

**NKL GmbH**  
**Birckichstr. 15**  
**D-74549 Wolpertshausen**

## Die wichtigsten Arten von Störungen und Abhilfen: The most important types of interference and remedies:

Symmetrische Störungen:  
Symmetrical interference:




Typische Störquellen, die symmetrische Störungen erzeugen, sind:  
Typical sources of symmetrical interferences:

Alle Arten von Gleichrichtern, Thyristor-Steuerungen wie z. B. Phasenanschnitt-Steuerungen, Halbleiter-Relais etc.

Symmetrische Störungen treten in der Praxis hauptsächlich leitungsgebunden im unteren Frequenzbereich bis ca. 1 MHz auf.

All types of rectifiers, thyristor controls such as e. g. generalized phase controls, semiconductor relays, etc.

In practice, symmetrical interferences occur mainly as conducted interference in the lower frequency range up to about 1 MHz.



Symmetrische Störungen werden entstört durch:  
Symmetrical interferences are suppressed by:

- Kondensatoren zwischen den Anschlüssen („X“-Kondensatoren): Diese schließen die Störströme kurz, bevor sie die Störsenke erreichen.
- capacitors between the terminals („X“ capacitors): they short-circuit the interference currents just before they reach the potentially susceptible equipment.
- Einzel-Drosseln im Strompfad der Zu- und Ableitungen. Diese Drosseln sind für symmetrische Störungen wirksam und erhöhen die Impedanz des symmetrischen Störstromkreises.
- single chokes in the current path of the incoming and outgoing lines. These chokes are effective for symmetrical interferences and increase the impedance of the symmetrical interference circuit.

Figure 5 : EMC – interferences and remedies



## EMC adequate design of switchgear cabinets and facilities

All devices with a metal housing or a connector for PE should be connected properly, i. e. short and with a large contact area to the mounting plate of the cabinet or the chassis of the machine to ensure a proper potential equalisation.

For that the insulation of the mounting plate has to be removed, especially below power drive systems and their respective filters.

The best solution is to use a conducting mounting plate that is zinc coated.




Figure 6 : EMC – adequate design of switchgear cabinets and facilities

## 5.3 Terminal assignment

Pin	d	b	z
2	0 V (External)	DIO 1 or S1.08	- Sign (direction) digital set values
4	Digital set value 2 (S1.02)	DIO 2	+ Sign (direction) digital set values
6	Digital set value 3 (S1.03)	DIO 3	Digital set value 4 (S1.04)
8	ENABLE (DI 1)	Analog input 1 (Option)	Digital set value 1 (S1.01)
10	Sensor 1 (FB 1) $U_E$ , $I_E$	Analog output	n/c
12	Analog set value 6 $U_{E+}$ (S1.06)	n/c	Analog set value 5 $U_{E+}$ (S1.05)
14	ERROR (DO 1)	COMPARATOR (DO 2)	Sensor 2 (FB 2) $U_E$
16	Analog set value 6 $U_{E-}$ (S1.06)	Analog input 2 (Option)	Analog set value 7 $I_E$ (S1.07)
18	Digital GND	PE	Reset Ramp (DI 2)
20	Reference output - 10.0 V	Break output 24 V / 1 A	Reference output + 10.0V
22	Solenoid output A -	Solenoid output A -	Solenoid output A -
24	Solenoid output B -	Solenoid output B -	Solenoid output B -
26	0 V (Power)	0 V (Power)	Analog GND
28	Solenoid output A +	Solenoid output A +	Solenoid output A +
30	Solenoid output B +	Solenoid output B +	Solenoid output B +
32	+ 24 V (Power)	+ 24 V (Power)	24 V (External)

Table 7: Terminal assignment

## 5.4 Picture of rear connector

Connector: IEC 60603-2 form F 48 pins




Figure 7 : Connector F48

## 5.5 Operation modes

The setting of parameter <E00> is determining which operation mode is activated. This parameter is factory preset! Only the mode relevant parameters are made available for each of the modes.

Available operation modes:




Figure 8 : Available Operation Modes

With the use of parameter <E00> any basic mode of operation may be selected. A change in operation modes will be effective immediately. Recalling the parameters for the newly chosen mode takes only a few seconds. During this time, the display flashes. Only the mode relevant parameter are made available.

<E00>	Mode description
1	Open loop, 1 proportional valve with 2 solenoids without feedback
2	Open loop, 2 proportional valves with 1 solenoid each without feedback
3	Closed loop valve, single, 1 proportional valve with 2 solenoids and feedback of spool position
4	Closed loop process, single, 1 proportional valve with 2 solenoids and feedback of process value (position, velocity, pressure, force, torque etc.)
5	Reserved
6	Closed loop valve and process, double, 1 proportional valve with 2 solenoids and feedback of spool position and additional feedback of process value (cascaded controller)
7	Reserved
8	Closed loop processes, double, 2 independent proportional valve with 1 solenoid each and feedback of two independent process values (e.g. two pressure control systems)
9	Reserved
10	Controller function without valve, control of 1 process value; provide set value to follow up electronics (e.g. valve with integrated electronics, frequency converter for AC motor etc.)
11	Controller function without valve, control of 2 process values (cascaded controller, e.g. position and velocity controller); provide set value to follow up electronics (e.g. valve with integrated electronics, frequency converter for AC motor etc.)

Table 8: Operation modes

## 5.6 Wiring diagrams for all operation modes

### 5.6.1 Wiring diagram for operation mode 01

Open loop, 1 proportional valve with 2 solenoids




Figure 9 : Wiring diagram Mode 01

## 5.6.2 Wiring diagram for operation mode 02

Open loop, 2 proportional valves with 1 solenoid each




Figure 10 : Wiring diagram Mode 02

### 5.6.3 Wiring diagram for operation mode 03

Closed loop, 1 proportional valve with 2 solenoids and spool position feedback




Figure 11 : Wiring diagram Mode 03

## 5.6.4 Wiring diagram for operation mode 04

Closed loop double, 1 proportional valve with 2 solenoids and feedback of a process value




Figure 12 : Wiring diagram Mode 04



## 5.6.5 Wiring diagram for operation mode 06

Closed loop double, 1 proportional valve with 2 solenoids and spool position and process value feedback




Figure 13 : Wiring diagram Mode 06



## 5.6.6 Wiring diagram for operation mode 08

Closed loop double, 2 proportional valves with 1 solenoid each and feedback of two independent process values




Figure 14 : Wiring diagram Mode 08

## 5.6.7 Wiring diagram for operation mode 10

Closed loop without valve, controller only




Figure 15 : Wiring diagram Mode 10

## 5.6.8 Wiring diagram for operation mode 11

Closed loop double (cascaded controller) without valve, controller only




Figure 16 : Wiring diagram Mode 11

## 6 Commissioning

### 6.1 Front elements

#### ⚠ WARNING

The electrical wiring must be checked before switching on the supply voltage. Limit switches and safety devices must be activated to avoid uncontrolled movements. Carefully follow relevant safety regulations. Suitable emergency stop measures must be taken.

#### 6.1.1 DAC-42(A)-x-PN




Figure 17 : DAC-42(A)-x-PN Front elements

Element	Function
Status LED's	Display of status, Power, Enable, Error.
Profinet LED's	Display of status of the profinet connection.
Profinet LED's	Display of status of the profinet connection.
Profinet connection's	Ethernet 2xRJ45 input/Output to the network
DIP-switch	Reserved, for further use
USB-C interface	Trough which programing and accessing parameters via PC and HCSTool is been executed. RS232 (optional)
Measuring and test jacks	Direct measurement of set point, actual value, solenoid currents and internal values via the monitor output. Use 2 mm sockets (S1.06, FB1, A, B, d1.01 ... d2.13)

Table 9: Front elements DAC-42(A)-x-PN explanation

## 6.2 Software block diagrams



All functions and parameter inside of the block diagrams are described in detail in the “DAC-4x(A) Manual E Rxx yyyyymmdd.pdf” please ask HCS GmbH if needed.

### 6.2.1 Operation Mode 01; 1 valve with 2 solenoids, open loop




Figure 18 : Software block diagram operation mode 1

## 6.2.2 Operation Mode 02; 2 valves with 1 solenoid each, open loop




Figure 19 : Software block diagram operation mode 2

## 6.2.3 Operation Mode 03; 1 valve with 2 solenoids and spool position feedback




Figure 20 : Software block diagram operation mode 3



## 6.2.4 Operation Mode 04; 1 valve with 2 solenoids and process value feedback




Figure 21 : Software block diagram operation mode 4





## 6.2.6 Operation Mode 08; 2 valves with 1 solenoid and process value feedback




Figure 23 : Software block diagram operation mode 8

## 6.2.7 Operation Mode 10; stand-alone controller with process feedback




Figure 24 : Software block diagram operation mode 10

## 6.2.8 Operation Mode 11; stand-alone controller with two process feedbacks




Figure 25 : Software block diagram operation mode 11

## 7 General communication information

### 7.1 Special information for bus activation

If communication via Profinet is required, there must be a connection to the power supply; supply via USB is not sufficient. The Profinet-Node connected to the PLC (Error LED is off). In addition, parameter E22 must be set to "on" or "1".

### 7.2 General information about TADR (Telegram Address)

TADR is a value which may be written (changed) with each cycle but changing of this value is optional and not mandatory. The value will be defined by the Profinet-Master.

The purpose is to either check the telegrams by the master or also in order to force sending of a new telegram from the node.

The design of the node is made in a way that the slave or slaves (module or modules in case of multi-slave version) are only responding if a received message from the master contains changed (different) data compared to the previous message.

So TADR can be used to force a response from a slave for example in order to get an update on the current status of the slave even if the other data in the message remain unchanged.

TADR value is valid in the range of 0 to 255 or in hexadecimal 0x00 to 0xFF.

### 7.3 General information about CMD (Command) and SADR (Slave Address)



**The SADR is used to address different slaves which are connected to the same Profinet-node. In case of the DAC-4x(A) the possibility of a Multi-Slave Nodes is not possible. The slave Address in the telegram must always set to "0" or "1"**

Different ways of communication between master and slaves (modules) are possible. The difference is in the CMD instruction.

- CMD = 6: Writing of a single parameter-ID to the DAC-4x(A). The Profinet node has only one slave (one DAC-4x(A) connected. In this case SADR is set to 1.  
□ [Chapter „8.3.1 CMD = 6, Master Write single parameter \(7 bytes\)“, page 44](#)
- CMD = 3: Reading of one or more parameters with parameter-ID in rising order. The Profinet node has only one slave (one DAC-4x(A) connected. In this case SADR is set to 1  
□ [Chapter „8.1.1 CMD = 3, Master Read parameters \(7 bytes\)“, page 42](#)
- CMD = 15: This instruction allows writing or reading of a (pre-defined) set of parameters. The set of parameters itself is depending on the software version of the DAC-4x(A); refer also to  
□ [Chapter „9.5 CMD = 15, structure of Profinet telegram definition, depending on SW Versions“, page 49](#)  
For more information please to □ [Chapter „9 Complex commands“, page 47](#)

It is possible to „mix“ the instructions CMD = 3, CMD = 6 and CM = 15 for the DAC-4x(A).



## 8 Simple commands

### 8.1 CMD 3 Master Read

#### 8.1.1 CMD = 3, Master Read parameters (7 bytes)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the user, Range 0..255, 0..0xFF
1	SADR = 01	Slave address
2	CMD	Command: 3 = Read multiple parameters by the master
3	IDH	High byte parameter ID of first parameter
4	IDL	Low byte parameter ID of first parameter
5	N-high	High-Byte Number parameters
6	N-low	Low-Byte Number parameters

...Write last

<b>TADR</b>	Telegram address, defined by the Profinet-Master.( Set by the User )
<b>SADR</b>	1 = standard (single slave)
<b>CMD</b>	Command: 3 = Read parameter by the master
<b>IDH,IDL</b>	H-Byte and Low-Byte of parameter-ID in HEX 0x0000 .. 0x0109 = Valid ID-Range. Please take into account the gaps in the parameter list
<b>N-high</b>	High-Byte Number parameters (words), normally zero
<b>N-low</b>	Low-Byte Number parameters (words), 1 to 8 (0x08) (maximal 8 parameters readable at once)

#### 8.1.2 CMD = 3, Response from Slave (4 + CNT bytes)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the read command, Range 0..255, 0..0xFF
1	SADR	Slave address
2	CMD	Command: 3 = Read multiple parameters by the master
3	CNT	N*2, Number of data bytes
4	DAT1H	High byte value of first parameter
5	DAT1L	Low Byte value of first parameter

If CNT > 2: .....

CNT+2 = N	DATnH	High byte value of last (n)parameter
CNT+3 = N	DATnL	Low Byte value of last (n)parameter

...Write last

<b>TADR</b>	Telegram address, defined by the Profinet-Master. (Set by the read command)
<b>SADR</b>	Slave address, 1 = standard (single slave)
<b>CMD</b>	Command: 3 = Read parameter by the master
<b>CNT</b>	N*2, Number of data bytes (Maximal 16 data bytes)
<b>IDH,IDL</b>	H-Byte and Low-Byte of parameter-ID in HEX 0x0000 .. 0x00109 = Valid ID-Range
<b>DAT1H.. DAT nH, DAT1L.. DAT nL,</b>	Two data bytes in HEX, without decimal sign 0x7FFF == +32767 0x8000 == -32768

## 8.1.3 CMD = 3, Error from DAC-4x(A) (4 bytes)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the read command, Range 0..255, 0..0xFF
1	SADR	Slave address
2	ERR	Error code
3	EXCE	Exception

...Write last

**ERR** Error code: 0x83 = Read failed

**EXCE** Exception:  
 1 = Command not supported  
 2 = Wrong ID  
 3 = CNT == 0 or CNT > 16 (0x10)  
 4 = Reading of ID failed  
 5 = timeout slave, address wrong or not installed or Invalid number of connected slaves  
 6 = Internal checksum error (Modbus)

Example for error response:

Module 3 is not installed and **SADR** in the master telegram is set to 3

Byte	Data	Abbreviation	Description
0	0x23	TADR	Response telegram address (defined by the read command)
1	0x01	SADR	Actual slave address
2	0x83	ERR	Error, Bit „7“ with command 0x03 is set
3	0x05	EXCE	timeout slave, address wrong or not installed

## 8.2 Telegram example CMD = 3

Master wants to read parameter „d1.07“:

ID = 0x0007  
 N = 0x01, (one parameter)  
 TADR = 0x24  
 SADR = 0x01 (always 1)

Byte	Data	Abbreviation
0	0x24	TADR
1	0x01	SADR
2	0x03	CMD
3	0x00	IDH
4	0x07	IDL
5	0x00	N-high
6	0x01	N-low

Response from slave (module)

CNT = 2 (2 Bytes)  
 DATA = 0x0133 (== 0.307A)

Byte	Data	Abbreviation
0	0x24	TADR
1	0x01	SADR
2	0x03	CMD
3	0x02	CNT
4	0x01	DAT1H
5	0x33	DAT1L



## 8.3 CMD = 6, Master Write

### 8.3.1 CMD = 6, Master Write single parameter (7 bytes)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the user, Range 0..255, 0..0xFF
1	SADR = 01	Slave address
2	CMD	Command: 6 = Write single parameter by the master
3	IDH	High byte parameter ID
4	IDL	Low byte parameter ID
5	DATH	High byte of parameter value
6	DATL	Low byte of parameter value

Write last

<b>TADR</b>	Telegram address, defined by the Profinet-Master.(Set by the user)
<b>SADR</b>	1 = standard (single slave)
<b>CMD</b>	Command: 6 = Write single parameter by the master
<b>IDH,IDL</b>	H-Byte and Low-Byte of parameter-ID in HEX 0x0000 .. 0x00B0 = Valid ID-Range
<b>DATH,DATL</b>	Two data bytes in HEX, without decimal sign 0x7FFF == +32767 0x8000 == -32768

### 8.3.2 CMD = 6, Response from DAC-4x(A) (7 bytes)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the write command, Range 0..255, 0..0xFF
1	SADR	Slave address
2	CMD	Command: 6 = Write single parameter by the master
3	IDH	High byte parameter ID
4	IDL	Low byte parameter ID
5	DATH	High byte of second analogue value
6	DATL	Low byte of first analogue value

Write last

<b>TADR</b>	Telegram address, defined by the Profinet-Master.( Set by the write command )
<b>SADR</b>	Slave address, 1 = standard (single slave)
<b>CMD</b>	Command: 6 = Write parameter by the master
<b>IDH,IDL</b>	H-Byte and Low-Byte of parameter-ID in HEX 0x0000 .. 0x0109 Valid ID-Range
<b>DATH,DATL</b>	Two data bytes in HEX, without decimal sign 0x7FFF == +32767 0x8000 == -32768

## 8.3.3 CMD = 6, Error from DAC-4x(A) (4 bytes)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the write command, Range 0..255, 0..0xFF
1	SADR	Slave address
2	ERR	Error code
3	EXCE	Exception

...Write last

**ERR** Error code: 0x86 = write failed

**EXCE** Exception:  
 1 = Command not supported  
 2 = Wrong ID  
 3 = Wrong Data Value  
 4 = Writing of ID failed  
 5 = timeout slave, address wrong or not installed or Invalid number of connected slaves  
 6 = Internal checksum error (Modbus)

Example for error response:

SADR 3 is not valid and **SADR** in the master telegram is set to 3

Byte	Data	Abbreviation	Description
0	0x23	TADR	Response telegram address (defined by the write command)
1	0x03	SADR	Actual slave address
2	0x86	ERR	Error, Bit „7“ with command 0x06 is set
3	0x05	EXCE	timeout slave, address wrong or not installed

## 8.4 Telegram example CMD = 6

### 8.4.1 Example, write parameter

Master wants to write parameter „C1.07“ with value 1.000 V:

ID = 0x0030  
 DATA = 0x3E8 (= 1000 in decimal)  
 TADR = 0x23  
 SADR = 0x01

Byte	Data	Abbreviation
0	0x23	TADR
1	0x01	SADR
2	0x06	CMD
3	0x00	IDH
4	0x30	IDL
5	0x03	DATL
6	0xE8	DATH

Response from slave (module), command was successful executed

ID = 0x0030  
 DATA = 0x3E8 (= 1.000 V)

Byte	Data	Abbreviation
0	0x23	TADR
1	0x01	SADR
2	0x06	CMD
3	0x00	IDH
4	0x30	IDL
5	0x03	DATL
6	0xE8	DATH

## 8.4.2 Example, write set value

Examples for set value via Profinet (ID = 0x0027):

1.) Command signal 0.000 V = 0x0000:

Byte	Data	Abbreviation
0	0x12	TADR
1	0x01	SADR
2	0x06	CMD
3	0x00	IDH
4	0x27	IDL
5	0x00	DATL
6	0x00	DATH

2.) Set value 5.000 V = 0x1388:

Byte	Data	Abbreviation
0	0x12	TADR
1	0x01	SADR
2	0x06	CMD
3	0x00	IDH
4	0x27	IDL
5	0x13	DATL
6	0x88	DATH

3.) Set value 9.999 V = 0x270F:

Byte	Data	Abbreviation
0	0x12	TADR
1	0x01	SADR
2	0x06	CMD
3	0x00	IDH
4	0x27	IDL
5	0x27	DATL
6	0x0F	DATH

4.) Set value -9.999 V = 0xD8F1

Byte	Data	Abbreviation
0	0x12	TADR
1	0x01	SADR
2	0x06	CMD
3	0x00	IDH
4	0x27	IDL
5	0xD8	DATL
6	0xF1	DATH

## 9 Complex commands

### 9.1 CMD = 15, Master writes multiple parameters (8 bytes) (Fast single-slave command)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the user, Range 0..255, 0..0xFF
1	SNUM = 01	Single slave, always 01
2	CMD	Command: 15 = Write multiple parameter by the master
3	DAT1.1	Control-Byte
4	DAT1.2H	High byte of first „analogue“ value
5	DAT1.2L	Low byte of first „analogue“ value
6	DAT1.3H	High byte of second „analogue“ value
7	DAT1.3L	Low byte of second „analogue“ value
Overall telegram length in bytes		

**TADR** Telegram address, defined by the Profinet-Master. (defined by the user) Range 0..255

**SNUM** Only one slave is connected. SNUM = 01.

**CMD** Command: 15 = Write multiple parameters by the master

**DAT1.1** Control-Byte. One data byte in HEX, for special functions  
0x00 == 0  
0xFF == 255

**DAT1.2H, DAT1.2L** Process Value1: Two data bytes in HEX, without decimal sign, for „analogue“ values  
0x7FFF == +32767  
0x8000 == -32768

**DAT1.3H, DAT1.3L** Process Value1: Two data bytes in HEX, without decimal sign, for „analogue“ values  
0x7FFF == +32767  
0x8000 == -32768

### 9.2 CMD = 15, Response from DAC-4x(A) (9 bytes)

This response telegram with SADR = 1 is send back by the DAC-4x(A).

Write first...

Byte	Structure	Abbreviation	Description
0	Telegram header	TADR	Telegram address, defined by the user, Range 0..255, 0..0xFF
1		SADR = 01	Slave address
2		CMD	Command: 15 = Write multiple parameter by the master
3	Data of SADR	DAT.1H	High byte of module state
4		DAT.1L	Low byte of module state
5		DAT.2H	High byte of first „analogue“ value
6		DAT.2L	Low byte of first „analogue“ value
7		DAT.3H	High byte of second „analogue“ value
8		DAT.3L	Low byte of second „analogue“ value

...Write last

**TADR** Telegram address, defined by the Profinet-Master.(set by the user)

**SADR** Slave address, normally always 01

**CMD** Command: 15 = Write multiple parameters by the master

**DAT.1H,DAT.1L** Status word. Two data bytes in HEX, , for module state  
0x0000 == 0  
0xFFFF == 65535

**DAT.2H, DAT.2L, DAT.3H, DAT.3L** VALUE1  
VALUE2. Two data bytes in HEX, without decimal sign, for analogue values  
0x7FFF == +32767  
0x8000 == -32768

## 9.3 CMD = 15, Error from DAC-4x(A) (4 bytes)

Write first...

Byte	Abbreviation	Description
0	TADR	Telegram address, defined by the write command, Range 0..255, 0..0xFF
1	SADR	Slave address
2	ERR	Error code
3	EXCE	Exception

...Write last

**ERR** Error code: 0x8F = write failed

**EXCE** Exception:  
 1 = Command not supported  
 2 = Wrong ID  
 3 = Wrong Data Value  
 4 = Writing of ID failed  
 5 = timeout (Modbus)  
 6 = Internal checksum error (Modbus)  
 7 = Invalid number of connected slaves  
 8 = timeout slave, address wrong or not installed  
 9 = Profinet node (SADR = 0) send, received data length to small. The data length of the selected GSD module is too small.

Example for error response:

Module 3 is not installed and SNUM in the master telegram is set to 3

Byte	Data	Abbreviation	Description
0	0x23	TADR	Response telegram address (defined by the write command)
1	0x03	SADR	Actual slave address
2	0x8F	ERR	Error, Bit „7“ with command 0x0F in decimal 15 is set
3	0x08	EXCE	timeout slave, address wrong or not installed

## 9.4 Examples, CMD = 15, single slave, DAC-4x(A)

E22 is set to 1 and hardware Enable is connected to the DAC-4x(A).

Master writes set value of 1.000 V to slave (module):

Byte	Data	Abbreviation	Description
0	0x23	TADR	Telegram address, defined by the user, Range 0..255, 0..0xFF
1	0x01	SNUM	0x01 means single slave
2	0x0F	CMD	0x0F in decimal 15
3	0x00	DAT1.1	<b>Control byte</b> , 0x00 (default value, no bus-disable)
4	(1000)	DAT1.2H	<b>Process Value1 = A1.01, set value branch 1</b> 0x03E8 ( = 1000 in decimal = 1.000V)
5		DAT1.2L	
6	(0)	DAT1.3H	<b>Process Value2 = A1.02, feedback value branch 1</b> 0x0000 ( = 0 in decimal = 0.000V)
7		DAT1.3L	

Response slave (module) no.1:

Byte	Data	Abbreviation	Description
0	0x23	TADR	Response telegram address (defined by the write command)
1	0x01	SADR	Actual slave address
2	0x0F	CMD	0x0F in decimal 15
3	0x40	DAT1.1H	<b>Status word</b> High byte of module state = 0x40 (HW enable = active)
4	0x00	DAT1.1L	
5	0x00	(0)	<b>VALUE1 = d1.11</b> 0x0000 ( = 0 in decimal = 0.000V )
6	0x00		
7	0x03	(1000)	<b>VALUE2 = d1.10</b> 0x03E8 ( = 1000 in decimal = 1.000V)
8	0xE8		

(x) = value in decimal.

## 9.5 CMD = 15, structure of Profinet telegram definition, depending on SW Versions

### 9.5.1 General

#### 9.5.1.1 Error Message (indication by „Error occurred“)

Errors which are indicated in the Bit (Error occurred) like for example „Over Current“ or „Cable Fraction“ can be reset with the following action :

- Set input signal for the hardware enable at the according module at terminal X3/1 (9) to „Low“ and then go back to „High“
- Setting and resetting of the Bits (0x80) Bus-Disable

Mandatory condition for resetting an error is that the failure causing the error has been cleared or removed.

#### Error numbers:

The corresponding error numbers can be found in the respective manual of the DAC-4x(A).

Generally, the following error table is valid:

Slave (Module) Status		Description
Hi-Byte (DAT.1H)	Low-Byte (DAT.1L)	
0x0C	0x01	Error of Operation
0x0C	0x02	Wire break at FB1 (voltage/current depend on setting)
0x0C	0x03	Excess current or short circuit at the output stages (peak current >8A!)
0x0C	0x04	Wire break at FB2 (voltage/current depend on setting)
0x0C	0x05	Wire break at S1.05 (voltage/current depend on setting)
0x0C	0x06	Wire break at S1.06 (voltage/current depend on setting)
0x0C	0x07	Wire break at S1.07 (voltage/current depend on setting)
0x0C	0x08	Underload of the solenoid output (if monitoring is activated)
0x0C	0x0A	Timeout error -no Profinet command recognized- (defined with parameter E23)
0x0C	0x0B	Over current at feedback FB1 (current signal >22mA)
0x0C	0x0C	Over current at feedback FB2 (current signal >22mA)
0x0C	0x0F	Over current at set point S1.05 (current signal >22mA)
0x0C	0x10	Over current at set point S1.06 (current signal >22mA)
0x0C	0x11	Over current at set point S1.07 (current signal >22mA)
0x0C	0x17	Selected Sensor need autocalibration.

Table 10: Error numbers

If parameter E 23 has a value not equal to 0 (Profinet timeout is activated). Depending on parameter E 26, there are different responses from the device.

- E 26 = off (0)  
The device reacts with a blinking enable LED about to long time between valid Profinet telegrams. Those versions continue with work if a new valid telegram is detected. No separate acknowledges with the enable signal is needed.
- E 26 = 1  
The device reacts with a shining Error LED about to long time between valid Profinet telegrams. Those versions do not continue with work if a new valid telegram is detected. A separate acknowledge with the enable signal is needed.

Generally, the electronic discards every set point in error case and the outputs will be disabled.

#### 9.5.1.2 Explanation for „Hardware Enable“ and „Software Disable“:

Generally speaking, the hardware enable must be present („high“ level) in order to get a signal (current) at the output stages. Besides the hardware enable a software disable can be used in order to „override“ the hardware enable. So even if the hardware signal is present, with the according software command the module can be disabled!

This means that the hardware enable can be hardwired and the software disable can be used in order to drop the output signal to zero or also in order to quit errors.



## 9.5.1.3 Explanation of special functions and module state bits

Attention: Functions and module state bits depend on the used SW version

<b>HW_ENABLE</b>	The „Enable“ signal (HW Enable pin 8d) is activated at the module.
<b>ERROR</b>	An Error has occurred in the DAC-4x(A). Different possible problems can cause this. Please refer to the manual for the according DAC-4x(A) version.
<b>BUS_DISABLE</b>	Enable signal was reset by means of Profinet (DAC-4x(A) is disabled). Switching off the HW enable also resets any pending <b>BUS_DISABLE</b>
<b>Din_1</b>	To enable the function for the „remote loop controller“ (function switches from open loop to closed loop) via the comparator „Comp_1“ is enabled and can be used. Additional mandatory condition: C1.00 must be set to 2 or 4! Remark: d1.12 and d1.13 remain at „0.000 V“ as long as the condition for activation „Din_1“ has not be set. This will prevent a premature activation of the comparator „Comp_1“.
<b>Dout_1/CL</b>	Indicates that the function „loop controller“ for the branch 1 is active. When the module is working in „remote loop“, the module is now working in closed loop mode. Additional mandatory conditions for transition from open loop to closed loop: <ul style="list-style-type: none"><li>• C1.00 must be set to 2 or 4</li><li>• Signal Din_1 must be present</li><li>• Comparator Comp_1 has to be outside of the window, hence signal Comp_1 = 0.</li></ul> The module will remain in closed loop operation as long as signal Din_1 stays on „High“.
<b>Comp_1</b>	Output signal of comparator „Comp_1“, s used in order to monitor the signal defined by C1.25. This signal can also be used in order to switches over from open to closed loop: 0 = comparator is not active (out of the determined limits and time delays) 1 = comparator is active (inside the determined limits and time delays).
<b>Comp_11</b>	Output signal of comparator „Comp_11“, is used in order to monitor the signal defined by C1.32 0 = comparator is not active (out of the determined limits and time delays) 1 = comparator is active (inside the determined limits and time delays).
<b>Din_2</b>	To enable the function for the „remote loop controller“ (function switches from open loop to closed loop) via the comparator „Comp_2“ is enabled and can be used. Additional mandatory condition: C2.00 must be set to 2 or 4! Remark: d2.12 and d2.13 remain at „0.000 V“ as long as the condition for activation „Din_2“ has not be set. This will prevent a premature activation of the comparator „Comp_2“.
<b>Dout_2</b>	Indicates that the function „loop controller“ for the branch 2 is active. When the module is working in „remote loop“, the module is now working in closed loop mode. Additional mandatory conditions for transition from open loop to closed loop: <ul style="list-style-type: none"><li>• C2.00 must be set to 2 or 4</li><li>• Signal Din_2 must be present</li><li>• Comparator Comp_2 has to be outside of the window, hence signal Comp_2 = 0.</li></ul> The module will remain in closed loop operation as long as signal Din_2 stays on „High“.
<b>Comp_2</b>	Output signal of comparator „Comp_2“, s used in order to monitor the signal defined by C2.25. This signal can also be used in order to switches over from open to closed loop: 0 = comparator is not active (out of the determined limits and time delays) 1 = comparator is active (inside the determined limits and time delays).
<b>Comp_22</b>	Output signal of comparator „Comp_22“, is used in order to monitor the signal defined by C2.32 0 = comparator is not active (out of the determined limits and time delays) 1 = comparator is active (inside the determined limits and time delays).
<b>TST_CMP</b>	This bit can be used to test the Set Error/Comp output. When set, the output is set to 24V, independent of the Comp_1/Comp_2 signal. To activate this function the parameter E 18 must be set to a value > 0 and no error is present.
<b>CNTRL_4</b>	Reserved for special function
<b>STAT_1..5</b>	Reserved for special functions

## 9.5.2 Version for Mode 1 (open loop, one valve with two solenoids)

Master writes multiple parameters (at all 8 bytes)

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by User, Range 0..255, 0..0xFF
	1		<b>SNUM = 1</b>	Single slave = 1
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Module Data	DAT1.1	<b>Control byte</b>   Byte for special functions
	4		DAT1.2H	<b>A1.01 Module 1</b>
	5		DAT1.2L	Set value input (Profinet)
	6		DAT1.3H	<b>A1.02 Module 1 (normally not used)</b>
	7		DAT1.3L	Set value input (Profinet)
....Write last		8	Overall telegram length in bytes	

Explanation of Byte for special functions (**Control byte**)

Description	Abbreviation	Function of each bit
Byte for special functions	DATx.1	<p>Can be set only if the hardware enable is active.</p> <p>0x01 = <b>not used</b></p> <p>0x04 = <b>TST_CMP</b>; Set Error/Comp output direct to 24V (disable signaling of error output)</p> <p>0x10 = <b>not used</b></p> <p>0x80 = <b>BUS_DISABLE</b> (Module disable via Profinet)</p> <p>In this mode not applicable, reserved:</p> <p>0x02 = CNTRL_1</p> <p>0x08 = CNTRL_2</p> <p>0x20 = CNTRL_3</p> <p>0x40 = CNTRL_4</p> <p>The special function byte will be set to internal 0x00 (reset) when the hardware enable is inactive.</p>

### Response telegram:

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by the write command
	1		<b>SADR</b>	Slave address
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Data of SADR Module	DAT.1H	<b>Status word</b>   High byte of module state
	4		DAT.1L	
	5		DAT.2H	<b>VALUE1</b> = d1.07
	6		DAT.2L	Actual current A
	7		DAT.3H	<b>VALUE2</b> = d1.08
	8		DAT.3L	Actual current B
....Write last		9	Overall telegram length in bytes	

Explanation of High and low byte of module state (**Status word**):

Description	Abbreviation	Explanation of each bit
High byte of module state	DAT.1H	<p>0x01 = Digital input <b>SP1</b> (S1.01) active *)</p> <p>0x02 = Digital input <b>SP2</b> (S1.02) active *)</p> <p>0x04 = <b>HW_ENABLE</b>, hardware enable active</p> <p>0x08 = <b>ERROR</b>, Error is pending</p> <p>0x10 = Digital input <b>SP3</b> (S1.03 active *)</p> <p>0x20 = Digital input <b>SP4</b> (S1.04 active *)</p> <p>0x80 = <b>BUS_DISABLE</b> is set</p> <p>In this mode not applicable, reserved:</p> <p>0x40 = <b>STAT_5</b></p>
Low byte of module state	DAT.1L	<p>if „Error occurred“ bit is set: error number</p> <p>otherwise:</p> <p>0x01 = <b>not used</b></p> <p>0x02 = <b>not used</b></p> <p>0x04 = <b>not used</b></p> <p>0x08 = <b>not used</b></p> <p>0x10 = <b>not used</b></p> <p>0x20 = <b>not used</b></p> <p>0x40 = <b>not used</b></p> <p>0x80 = <b>not used</b></p>

\*) The designation and availability of the input depends on the module variant.

## 9.5.3 Version for Mode 2 (open loop, two valves with one solenoid each)

Master writes multiple parameters (at all 8 bytes)

Write first...

Comment	Byte	Structure	Abbreviation	Description	
	0	Telegram header	TADR	Telegram address, defined by User, Range 0..255, 0..0xFF	
	1		SNUM = 1	Single slave = 1	
	2		CMD	Command: 15 = Write multiple parameter by the master	
	3	Module Data	DAT1.1	Control byte	Byte for special functions
	4		DAT1.2H	A1.01, set value input (Profinet) for (Branch 1)	
	5		DAT1.2L		
	6		DAT1.3H	A2.01, set value input (Profinet) for (Branch 2)	
	7		DAT1.3L		
....Write last		8	Overall telegram length in bytes		

Explanation of Byte for special functions (**Control byte**)

Description	Abbreviation	Function of each bit
Byte for special functions	DATx.1	<p>Can be set only if the hardware enable is active.</p> <p>0x01 = not used</p> <p>0x04 = <b>TST_CMP</b>; Set Error/Comp output direct to 24V (disable signaling of error output)</p> <p>0x10 = not used</p> <p>0x80 = <b>BUS_DISABLE</b> (Module disable via Profinet)</p> <p>In this mode not applicable, reserved:</p> <p>0x02 = CNTRL_1</p> <p>0x08 = CNTRL_2</p> <p>0x20 = CNTRL_3</p> <p>0x40 = CNTRL_4</p> <p>The special function byte will be set to internal 0x00 (reset) when the hardware enable is inactive.</p>

**Response telegram:**

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by the write command
	1		<b>SADR</b>	Slave address
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Data of SADR Module	DAT.1H	<b>Status word</b>   High byte of module state
	4		DAT.1L	
	5		DAT.2H	<b>VALUE1</b> = d1.07
	6		DAT.2L	Actual current A
	7		DAT.3H	<b>VALUE2</b> = d1.08
	8		DAT.3L	Actual current B
....Write last		9	Overall telegram length in bytes	

Explanation of High and low byte of module state (**Status word**):

Description	Abbreviation	Explanation of each bit
High byte of module state	DAT.1H	<p>0x01 = Digital input <b>SP1</b> (S1.01) active *)</p> <p>0x02 = Digital input <b>SP2</b> (S1.02) active *)</p> <p>0x04 = <b>HW_ENABLE</b>, hardware enable active</p> <p>0x08 = <b>ERROR</b>, Error is pending</p> <p>0x10 = Digital input <b>SP3</b> (S2.01) active *)</p> <p>0x20 = Digital input <b>SP4</b> (S2.02) active *)</p> <p>0x80 = <b>BUS_DISABLE</b> is set</p> <p>In this mode not applicable, reserved:</p> <p>0x40 = <b>STAT 5</b></p>
Low byte of module state	DAT.1L	<p>if „Error occurred“ bit is set: error number</p> <p>otherwise:</p> <p>0x01 = not used</p> <p>0x02 = not used</p> <p>0x04 = not used</p> <p>0x08 = not used</p> <p>0x10 = not used</p> <p>0x20 = not used</p> <p>0x40 = not used</p> <p>0x80 = not used</p>

\*) The designation and availability of the input depends on the module variant.

## 9.5.4 Version for Mode 3, 4, 10 (closed loop)

Master writes multiple parameters (at all 8 bytes)

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by User, Range 0..255, 0..0xFF
	1		<b>SNUM = 1</b>	Single slave = 1
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Module Data	DAT1.1	<b>Control byte</b>   Byte for special functions
	4		DAT1.2H	<b>Process Value1 = A1.01</b>
	5		DAT1.2L	Set value input (Profinet) for (Branch 1)
	6		DAT1.3H	<b>Process Value2 = A1.02</b>
	7		DAT1.3L	Feedback value input (Profinet) for (Branch 1)
....Write last		8		Overall telegram length in bytes

↓

Explanation of Byte for special functions (**Control byte**)

Description	Abbreviation	Function of each bit
Byte for special functions	DATx.1	<p>Can be set only if the hardware enable is active.</p> <p>0x01 = <b>Din_1</b>; Set signal Din_1 to active</p> <p>0x04 = <b>TST_CMP</b>; Set Error/Comp output direct to 24V (disable signaling of error output)</p> <p>0x10 = <b>Din_2</b>; Set signal Din_2 to active</p> <p>0x80 = <b>BUS_DISABLE</b> (Module disable via Profinet)</p> <p>In this mode not applicable, reserved:</p> <p>0x02 = CNTRL_1</p> <p>0x08 = CNTRL_2</p> <p>0x20 = CNTRL_3</p> <p>0x40 = CNTRL_4</p> <p>The special function byte will be set to internal 0x00 (reset) when the hardware enable is inactive.</p>

### Response telegram:

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by the write command
	1		<b>SADR</b>	Slave address
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Data of SADR Module	DAT.1H	<b>Status word</b>   High byte of module state
	4		DAT.1L	
	5		DAT.2H	<b>VALUE1 = d1.11</b>
	6		DAT.2L	Actual value, feedback value (Branch 1)
	7		DAT.3H	<b>VALUE2 = d1.10</b>
	8		DAT.3L	Set value (internal value) (Branch 1)
....Write last		9		Overall telegram length in bytes

↓

Explanation of High and low byte of module state (**Status word**):

Description	Abbreviation	Explanation of each bit
High byte of module state	DAT.1H	<p>0x01 = Digital input <b>SP1</b> (S1.01) active *)</p> <p>0x02 = Digital input <b>SP2</b> (S1.02) active *)</p> <p>0x04 = <b>HW_ENABLE</b>, hardware enable active</p> <p>0x08 = <b>ERROR</b>, Error is pending</p> <p>0x10 = Digital input <b>SP3</b> (S2.01) active *)</p> <p>0x20 = Digital input <b>SP4</b> (S2.02) active *)</p> <p>0x80 = <b>BUS_DISABLE</b> is set</p> <p>In this mode not applicable, reserved:</p> <p>0x40 = <b>STAT 5</b></p>
Low byte of module state	DAT.1L	<p>if „Error occurred“ bit is set: error number</p> <p>otherwise:</p> <p>0x01 = <b>Din_1</b> active</p> <p>0x02 = <b>Dout_1</b> active</p> <p>0x04 = <b>Comp_1</b> active</p> <p>0x08 = <b>Comp_11</b> active</p> <p>0x10 = <b>Din_2</b> active</p> <p>0x20 = <b>Dout_2</b> active</p> <p>0x40 = <b>Comp_2</b> active</p> <p>0x80 = <b>Comp_22</b> active</p>

\*) The designation and availability of the input depends on the module variant.

## 9.5.5 Version for Mode 6, 11 (two closed loops)

Master writes multiple parameters (at all 8 bytes)

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by User, Range 0..255, 0..0xFF
	1		<b>SNUM = 1</b>	Single slave = 1
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Module Data	DAT1.1	<b>Control byte</b>   Byte for special functions
	4		DAT1.2H	<b>Process Value1 = A1.01</b>
	5		DAT1.2L	Set value input (Profinet) for (Branch 1)
	6		DAT1.3H	<b>Process Value2 = A2.02</b>
	7		DAT1.3L	Feedback value input (Profinet) for (Branch 2)
....Write last		8		Overall telegram length in bytes

↓

Explanation of Byte for special functions (**Control byte**)

Description	Abbreviation	Function of each bit
Byte for special functions	DATx.1	<p>Can be set only if the hardware enable is active.</p> <p>0x01 = <b>Din_1</b>; Set signal Din_1 to active</p> <p>0x04 = <b>TST_CMP</b>; Set Error/Comp output direct to 24V (disable signaling of error output)</p> <p>0x10 = <b>Din_2</b>; Set signal Din_2 to active</p> <p>0x80 = <b>BUS_DISABLE</b> (Module disable via Profinet)</p> <p>In this mode not applicable, reserved:</p> <p>0x02 = CNTRL_1</p> <p>0x08 = CNTRL_2</p> <p>0x20 = CNTRL_3</p> <p>0x40 = CNTRL_4</p> <p>The special function byte will be set to internal 0x00 (reset) when the hardware enable is inactive.</p>

**Response telegram:**

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by the write command
	1		<b>SADR</b>	Slave address
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Data of SADR Module	DAT.1H	<b>Status word</b>   High byte of module state
	4		DAT.1L	
	5		DAT.2H	<b>VALUE1 = d1.11</b>
	6		DAT.2L	Actual value, feedback value (Branch 1)
	7		DAT.3H	<b>VALUE2 = d2.11</b>
	8		DAT.3L	Actual value, feedback value (Branch 2)
....Write last		9		Overall telegram length in bytes

↓

Explanation of High and low byte of module state (**Status word**):

Description	Abbreviation	Explanation of each bit
High byte of module state	DAT.1H	<p>0x01 = Digital input <b>SP1</b> (S1.01) active *)</p> <p>0x02 = Digital input <b>SP2</b> (S1.02) active *)</p> <p>0x04 = <b>HW_ENABLE</b>, hardware enable active</p> <p>0x08 = <b>ERROR</b>, Error is pending</p> <p>0x10 = Digital input <b>SP3</b> (S2.01) active *)</p> <p>0x20 = Digital input <b>SP4</b> (S2.02) active *)</p> <p>0x80 = <b>BUS_DISABLE</b> is set</p> <p>In this mode not applicable, reserved:</p> <p>0x40 = <b>STAT 5</b></p>
Low byte of module state	DAT.1L	<p>if „Error occurred“ bit is set: error number</p> <p>otherwise:</p> <p>0x01 = <b>Din_1</b> active</p> <p>0x02 = <b>Dout_1</b> active</p> <p>0x04 = <b>Comp_1</b> active</p> <p>0x08 = <b>Comp_11</b> active</p> <p>0x10 = <b>Din_2</b> active</p> <p>0x20 = <b>Dout_2</b> active</p> <p>0x40 = <b>Comp_2</b> active</p> <p>0x80 = <b>Comp_22</b> active</p>

\*) The designation and availability of the input depends on the module variant.

## 9.5.6 Version for Mode 8 (closed loop)

Master writes multiple parameters (at all 8 bytes)

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by User, Range 0..255, 0..0xFF
	1		<b>SNUM = 1</b>	Single slave = 1
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Module Data	DAT1.1	<b>Control byte</b>   Byte for special functions
	4		DAT1.2H	<b>Process Value1 = A1.01</b>
	5		DAT1.2L	Set value input (Profinet) for (Branch 1)
	6		DAT1.3H	<b>Process Value2 = A2.01 S</b>
	7		DAT1.3L	Set value input (Profinet) for (Branch 2)
....Write last		8	Overall telegram length in bytes	

↓

Explanation of Byte for special functions (**Control byte**)

Description	Abbreviation	Function of each bit
Byte for special functions	DATx.1	<p>Can be set only if the hardware enable is active.</p> <p>0x01 = <b>Din_1</b>; Set signal Din_1 to active</p> <p>0x04 = <b>TST_CMP</b>; Set Error/Comp output direct to 24V (disable signaling of error output)</p> <p>0x10 = <b>Din_2</b>; Set signal Din_2 to active</p> <p>0x80 = <b>BUS_DISABLE</b> (Module disable via Profinet)</p> <p>Not applicable, reserved:</p> <p>0x02 = CNTRL_1</p> <p>0x08 = CNTRL_2</p> <p>0x20 = CNTRL_3</p> <p>0x40 = CNTRL_4</p> <p>The special function byte will be set to internal 0x00 (reset) when the hardware enable is inactive.</p>

### Response telegram:

Write first...

Comment	Byte	Structure	Abbreviation	Description
	0	Telegram header	<b>TADR</b>	Telegram address, defined by the write command
	1		<b>SADR</b>	Slave address
	2		<b>CMD</b>	Command: 15 = Write multiple parameter by the master
	3	Data of SADR Module	DAT.1H	<b>Status word</b>   High byte of module state
	4		DAT.1L	
	5		DAT.2H	<b>VALUE1 = d1.11</b>
	6		DAT.2L	Actual value, feedback value (Branch 1)
	7		DAT.3H	<b>VALUE2 = d2.11</b>
	8		DAT.3L	Actual value, feedback value (Branch 2)
....Write last		9	Overall telegram length in bytes	

↓

Explanation of High and low byte of module state (**Status word**):

Description	Abbreviation	Explanation of each bit
High byte of module state	DAT.1H	<p>0x01 = Digital input <b>SP1</b> (S1.01) active *)</p> <p>0x02 = Digital input <b>SP2</b> (S1.02) active *)</p> <p>0x04 = <b>HW_ENABLE</b>, hardware enable active</p> <p>0x08 = <b>ERROR</b>, Error is pending</p> <p>0x10 = Digital input <b>SP3</b> (S2.01) active *)</p> <p>0x20 = Digital input <b>SP4</b> (S2.02) active *)</p> <p>0x80 = <b>BUS_DISABLE</b> is set</p> <p>In this mode not applicable, reserved:</p> <p>0x40 = <b>STAT 5</b></p>
Low byte of module state	DAT.1L	<p>if „Error occurred“ bit is set: error number</p> <p>otherwise:</p> <p>0x01 = <b>Din_1</b> active</p> <p>0x02 = <b>Dout_1</b> active</p> <p>0x04 = <b>Comp_1</b> active</p> <p>0x08 = <b>Comp_11</b> active</p> <p>0x10 = <b>Din_2</b> active</p> <p>0x20 = <b>Dout_2</b> active</p> <p>0x40 = <b>Comp_2</b> active</p> <p>0x80 = <b>Comp_22</b> active</p>

\*) The designation and availability of the input depends on the module variant.




## 10 Configuration for SIEMENS TIA portal

Two Profinet function blocks for the Siemens TIA portal are available, and can be downloaded from the HCS web side. Which one, the user should take, is depending on the used CPU family.


- Siemens CPU series S7-300,400 PN\_DAC4a\_CLASSIC\_DB(Vxx).scl
- Siemens CPU series S7-1200,1500 PN\_DAC4a\_DB.scl(Vxx).scl

### 10.1 Setup the network configuration for the DAC-4x(A)


Download and install the GSD file



Add new "Distributed I/O" and connect The DAC-4x(A) to the network.




### 10.2 Assign the IO-Module from the GSD to the device




## 10.3 Install the function block

Add new external file, Chose the function block according your used CPU series


- Siemens CPU series S7-300,400 PN\_DMA\_2\_CLASSIC\_DB(Vxx).scl
- Siemens CPU series S7-1200,1500 PN\_DMA\_2\_DB.scl(Vxx).scl



Right click on the selected file and “Generate blocks from the source”



After generation the function block is now available




## 10.4 Explanation of the function block

### 10.4.1 General

In this chapter we describe, how to use the function block in the different modes.

The structure and function for CMD 3, CMD 6 is the same in every working mode of the DAC-4x(A). Only the CMD 15 differs depending on the DAC-4x(A) operation mode.



The Bus slave address SNUM of the connected DAC-4x(A) is fixed and is set to "1" (single slave).

■ SNUM Int

The COM\_ERROR is obtained from the telegram header, which is transmitted from the Profinet node to the PLC. When this error is pending, the slave address source and the cause can be found out by analyze the COM\_EXCE code. (See [Chapter "8.1.3 CMD = 3, Error from DAC-4x\(A\) \(4 bytes\)"](#), page 43 or [Chapter "8.3.3 CMD = 6, Error from DAC-4x\(A\) \(4 bytes\)"](#), page 45

Reset an communication error can by set the input #COM\_RESET

■ COM\_RESET Bool


An GLOBAL\_ERROR occurs if any communication error or/and internal DMA-2 error is pending.

■ GLOBAL\_ERROR Bool

10.4.2 Classic CPU 300,400: Definition of the data buffer address

Unlike the CPU 1200, 1500, the E-address and A-address must be assigned to the variables #ADR\_IN and #ADR\_OUT here.


Add the IN/OUT module



The data buffer address #ADR\_IN, #ADR\_OUT is predefined to 256.



Please check the correct address of your system and change the value if necessary.



## 10.4.3 CPU 1200,1500: Specification of the data buffer address based on the hardware identifier

In contrast to CPU 300, 400, the hardware ID for the GSD I / O module must be assigned to the variable #DEV\_ID.  
The hardware-ID can be found here:

The screenshot shows the HW Config interface for a Siemens PLC system. The 'Device overview' table on the right lists the modules:


Module	Rack	Slot	I address	Q address	Type
dac-xx-pn	0	0			Standard, MRP
Interface	0	0 X1			dac-xx-pn
IN/OUT 42 bytes_1	0	1	43...84	43...84	IN/OUT 42 bytes

The 'Properties' window for 'IN/OUT 42 bytes\_1' is shown below, with the 'System constants' tab selected. The 'Name' is 'dac-xx-pn~IN\_OUT\_42\_bytes\_1', 'Type' is 'Hw\_SubModule', 'Hardware identi.' is '277', and 'Used by' is 'PLC\_1'.


Please check the correct address of your system and change the value if necessary.

PN_DAC_4a										
Name	Data type	Offset	Default value	Accessible f...	Writa...	Visible in ...	Setpoint	Supervision	Comment	
Input										
COM_RESET	Bool	0.0	false	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Reset the communication error if pendin..	
CMD	Int	2.0	0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Set the command for operation (CMD3,...	
IN_CMD15	Struct	4.0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Input structure for CMD 15	
IN_CMD6	Struct	10.0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Input structure for CMD 6	
IN_CMD3	Struct	14.0		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Input structure for CMD 3	
DEV_ID	HW_IO	18.0	277	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	ID of the I/O Module	

The data buffer address #ADR\_IN, #ADR\_OUT is predefined in this example at 277.



Please check the correct IP address of the device and change the value if necessary.  
In this example we have the 192.168.1.86 as the IP address for the DAC-4x(A)



## 10.4.4 CMD 3, Reading values from one DAC-4x(A) node

The DAC-4x(A) connected to the Profinet has a fix SNUM (slave number). Together with this number it is possible to read a set of parameter of this device.

The parameter-ID's are shown in table [Chapter "11 List of parameters", page 64](#)

An reading access is done as followed:

- The predefined slave number SNUM for the DAC4x(A) is 1.

■ SNUM Int

For slave 1 #SNUM := 1;

- Setup the CMD:

■ CMD Int

# CMD := 3;

- Write the starting address of the first parameter ID which should be read by the structure

■ IN\_CMD3 Struct  
■ PAR\_ID Int

E.g. parameter 22, S1.01 #IN\_CMD3.PAR\_ID := 22;

- Define the number of parameters to be read (maximum 8).

■ IN\_CMD3 Struct  
■ PAR\_ID Int  
■ PAR\_N Int

E.g. 4 parameters S1.01..S1.04 #IN\_CMD3.PAR\_N := 4;

- Definition of the states in #CMD3\_STAT:

■ CMD_UNSED	Int	0
■ CMD_START	Int	1
■ CMD_PROGRESS	Int	2
■ CMD_FINISH	Int	4
■ CMD_FAIL	Int	8

0: no action

1: Start of reading



- 2: Reading in process
- 4: Reading finished
- 8: Reading error occurred.

- Start the process, by writing `#CMD3_STAT := 1; (CMD_START)`

<code>CMD3_STAT</code>	Int
------------------------	-----

- When `#CMD3_STAT` reaches the value 4 (`CMD_FINISH`), Reading is finished, and the values can be read in the structure `#OUT_CMD.VALUE[1..8]`. In addition, the number of received bytes will be shown in the structure `#OUT_CMD.CNT`. Every read parameter needs 2 bytes.

<code>OUT_CMD3</code>	Struct
<code>CNT</code>	Int
<code>VALUE</code>	Array[1..8] of Int
<code>VALUE[1]</code>	Int
<code>VALUE[2]</code>	Int
<code>VALUE[3]</code>	Int

- If a reading error occurred, the reason for the error can be analyzed by checking the `#COM_xxxxx` outputs of the function block.

<code>COM_ERROR</code>	Bool
<code>COM_NUM</code>	Int
<code>COM_EXCE</code>	Int

## 10.4.5 CMD 6, Writing parameters the DAC-4x(A)

The written values are stored in a non-volatile memory.

The DAC-4x(A) connected to the Profinet has a fix SNUM (slave number). Together with this number it is possible to write a new parameter value to the parameter ID of this device.

The parameter-ID's are shown in table [Chapter "11 List of parameters", page 64](#)

An parameter writing access is done as followed:

- The predefined slave number SNUM for the DAC4x(A) is 1.

<code>SNUM</code>	Int
-------------------	-----

For slave 1 `#SNUM := 1;`

- Setup the CMD: `# CMD := 6;`

<code>CMD</code>	Int
------------------	-----

- Define the parameter ID and the value which should be changed.

<code>IN_CMD6</code>	Struct
<code>PAR_ID</code>	Int
<code>PAR_VALUE</code>	Int

E.g. parameter 22, S1.01 =1000 (1.0 V)

`#IN_CMD3.PAR_ID := 22;`  
`#IN_CMD3.PAR_VALUE := 1000;`

- Definition of the states in `#CMD6_STAT`:

<code>CMD_UNUSED</code>	Int	0
<code>CMD_START</code>	Int	1
<code>CMD_PROGRESS</code>	Int	2
<code>CMD_FINISH</code>	Int	4
<code>CMD_FAIL</code>	Int	8

- 0: no action
- 1: Start of writing
- 2: Writing in process
- 4: Writing finished
- 8: Writing error occurred.

- Start the process, by writing `#CMD6_STAT := 1; (CMD_START)`

<code>CMD6_STAT</code>	Int
------------------------	-----

- When `#CMD6_STAT` reaches the value 4 (`CMD_FINISH`), writing is finished

- If an writing error occurred, the reason for the error can be analyzed by checking the `#COM_xxxxx` outputs of the function block.

<code>COM_ERROR</code>	Bool
<code>COM_NUM</code>	Int
<code>COM_EXCE</code>	Int

## 10.4.6 CMD 15, Writing and Reading once the connected DAC-4x(A)

The CMD 15 makes it possible to send and receive process data from the DAC4-4x(A) connected to the Profinet node. The meaning of the process values depending on the mode of the DAC4-4x(A) is working at.

See [□ Chapter "9.5 CMD = 15, structure of Profinet telegram definition, depending on SW Versions", page 49](#)

Also, the Control-Byte is depending on the working mode. Explanation of the bits

See [□ Chapter "9.5.1.3 Explanation of special functions and module state bits", page 50](#)

An CMD 15 access is done as followed:

- Define the number of slaves SNUM of the modules connected to the Profinet node. In case of DAC-4x(A), only a single slave can be connected.

SNUM	Int
------	-----

For single slave

#SNUM := 1;

- Setup the CMD:

CMD	Int
-----	-----

# CMD := 15;

- Write the process data you want to the DAC-4x(A) in the structure provided.
- 

IN_CMD15	Struct	} DAC-4x(A) input structure

Structure of the transmit data set:

IN_CMD15	Struct	
BUS_DISABLE	Bool	
Din_1	Bool	
Din_2	Bool	
TST_CMP	Bool	
CNTRL_1	Bool	} Control Byte
CNTRL_2	Bool	
CNTRL_3	Bool	
CNTRL_4	Bool	
VALUE1	Int	
VALUE2	Int	} Process values to DAC-4x(A)

- Structure of the receive data set

OUT_CMD15	Struct	
HW_ENABLE	Bool	
BUS_DISABLE	Bool	
STAT_1	Bool	
STAT_2	Bool	
STAT_3	Bool	
STAT_4	Bool	
STAT_5	Bool	
ERROR	Bool	
ERROR_NO	Byte	
Din_1	Bool	} Status Word
Dout_1	Bool	
DKOMP_1	Bool	
DKOMP_11	Bool	
Din_2	Bool	
Dout_2	Bool	
DKOMP_2	Bool	
DKOMP_22	Bool	
VALUE1	Int	
VALUE2	Int	} Process values from DAC-4x(A)

- If an error has occurred, the cause of the error can be analyzed by evaluating the outputs #COM\_xxxxx of the function block.

COM_ERROR	Bool
COM_NUM	Int
COM_EXCE	Int

## 11 List of parameters

Parameters in grey letters are not yet implemented in the DMA Software.  
 All values in decimal, for usage as data values they must be converted into Hex  
 R = read only parameter.  
 X = implemented, but not active (no access)  
 W/R = writing and reading possible.

ID <sub>Hex</sub>	ID <sub>dec</sub>	W/R	Name	Function	Unit	Min	Max	Def	Description
0x00	0	R	Vers	Software version	---	xx.xx	xx.xx	xx.xx	Depends on HW and SW version
0x01	1	R	d1.01	Sum of analogue set value	V	-9999	9999	-	-1000 == -1.000 V; 1000 == 1.000 V
0x02	2	R	d1.02	Sum of all post ramp set values	V	-9999	9999	-	
0x03	3	R	d1.03	Set values after linearization	V	-9999	9999	-	
0x04	4	R	d1.04	Value after gain adjustment.	V	-9999	9999	-	
0x05	5	R	d1.05	Signal A	V	-9999	9999	-	
0x06	6	R	d1.06	Signal B	V	-9999	9999	-	
0x07	7	R	d1.07	Current A	A	0	5000	-	1000 == 1.000 A
0x08	8	R	d1.08	Current B	A	0	5000	-	
0x09	9	R	d1.09	Total current	A	0	5000	-	
0x0A	10	R	d1.10	Desired value	V	-9999	9999	-	-1000 == -1.000 V; 1000 == 1.000 V
0x0B	11	R	d1.11	Actual value, feedback value	V	-9999	9999	-	
0x0C	12	R	d1.12	Lag error	V	-9999	9999	-	
0x0D	13	R	d1.13	Controller output	V	-9999	9999	-	
0x0E	14	R	d2.01	Sum of analogue set value	V	-9999	9999	-	
0x0F	15	R	d2.02	Sum of all post ramp set values	V	-9999	9999	-	
0x10	16	R	d2.03	Set values after linearization	V	-9999	9999	-	
0x11	17	R	d2.04	Value after gain adjustment.	V	-9999	9999	-	
0x12	18	R	d2.10	Desired value	V	-9999	9999	-	
0x13	19	R	d2.11	Actual value, feedback value	V	-9999	9999	-	
0x14	20	R	d2.12	Lag error	V	-9999	9999	-	
0x15	21	R	d2.13	Controller output	V	-9999	9999	-	
0x16	22	R/W	S1.01	Set Value1	V	-9999	9999	0	
0x17	23	R/W	S1.02	Set Value2	V	-9999	9999	0	
0x18	24	R/W	S1.03	Set Value3	V	-9999	9999	0	
0x19	25	R/W	S1.04	Set Value4	V	-9999	9999	0	
0x1A	26	---	S1.08	reserved	---	---	---	---	
0x1B	27	R/W	r1.01	Ramp from 0 □ -	s	0	3950	0	1 == 10ms 0 == Ramp function off
0x1C	28	R/W	r1.02	Ramp from - □ 0	s	0	3950	0	
0x1D	29	R/W	r1.03	Ramp from 0 □ +	s	0	3950	0	
0x1E	30	R/W	r1.04	Ramp from + □ 0	s	0	3950	0	
0x1F	31	R/W	A1.01	Profinet set value (Branch 1)	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V This value is, when written, always active. Cleared by reset, or writing "0". For switching off of the analogue set-value, set E17 = "2"
0x20	32	R/W	A1.02	Profinet feedback value (Branch 1)	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V C1.09 has to be switched off in order to avoid interferences
0x21	33	R/W	S2.01	Set Value1 (Branch 2)	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0x22	34	R/W	S2.02	Set Value2 (Branch 2)	V	-9999	9999	0	
0x23	35	R/W	r2.01	Ramp from 0 □ -	s	0	3950	0	1 == 10ms 0 == Ramp function off
0x24	36	R/W	r2.02	Ramp from - □ 0	s	0	3950	0	
0x25	37	R/W	r2.03	Ramp from 0 □ + (Branch 2)	S	0	3950	0	
0x26	38	R/W	r2.04	Ramp from + □ 0 (Branch 2)	S	0	3950	0	
0x27	39	R/W	A2.01	Profinet set value (Branch 2)	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V This value is, when written, always active. Cleared by reset, or writing "0". For switching off of the analogue set-value, set E17 = "2"
0x28	40	R/W	A2.02	Profinet feedback value (Branch 2)	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V C2.09 has to be switched off in order to avoid interferences
0x29	41	R/W	C1.00	Controller selection	---	0	4	1	0 = off 1 = P-PT1-I-DT1 2 = Remote 3 = dff 4 = Remote + dff
0x2A	42	R/W	C1.01	Safety function	---	0	1	0	0 = off; 1 = on
0x2B	43	R/W	C1.02	Linearization	---	0	6	0	0 = linear 1 ... 5 = standard curves 6 = customized curve
0x2C	44	R/W	C1.03	Gain A	V/V	0	200	100	100 == Factor 1.00
0x2D	45	R/W	C1.04	Gain B	V/V	0	200	100	100 == Factor 1.00

ID <sub>Hex</sub>	ID <sub>dec</sub>	W/R	Na me	Function	Unit	Min	Max	Def	Description
0x2E	46	R/W	C1.05	Set value sign and gain	V/V	-400	400	100	100 == Factor 1.00 Sign and gain!
0x2F	47	R/W	C1.06	Set value offset	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0x30	48	R/W	C1.07	Dead band compensation A	V	0	9999	0	1000 == 1.000 V
0x31	49	R/W	C1.08	Dead band compensation B	V	0	9999	0	9.999 V = max. current depending on solenoid selection
0x32	50	R/W	C1.09	Sensor type  Attention: No negative controller output possible when 10, 11 or 12 is selected!	---	1	28	4	off = Deactivated 1 = 0...20mA 2 = 4...20mA 3 = 12mA +-8mA 4 = 0...10V 5 = 0...+-10V 6 = 6V +-2.5V 7 = 7.5V +-2.5V 8 = 6V +-5V 9 = 7,5 +-5V> 10 = 0..20mA (positive contr. outp. only) 11 = 4..20mA (positive contr. outp. only) 12 = 0..10V (positive contr. outp. only) 13 = reserved 14 = 5V+-3.0V 15..27 = reserved 28 = 5V+-2.6V
0x33	51	R/W	C1.10	Actual value gain	V/V	0	400	100	100 == Factor 1.00
0x34	52	R/W	C1.11	Actual value offset	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0x35	53	R/W	C1.12	Actual value sign	---	- 1	+ 1	1	- 1 = negative 0 = off + 1 = positive
0x36	54	R/W	C1.13	P-Portion Kp1	V/V	0	400	0	100 == Factor 1.00
0x37	55	R/W	C1.14	T-Portion for PT1 (to C1.16)	S	0	1000	0	100 == 1.00
0x38	56	R/W	C1.15	Threshold (C1.13, C1.16)	V	0	9999	9999	1000 == 1.000 V
0x39	57	R/W	C1.16	P-Portion Kp2	V/V	0	400	0	100 == Factor 1.00
0x3A	58	R/W	C1.17	I-Portion	V/s	0	4000	0	1000 == 1.000
0x3B	59	R/W	C1.18	D-Portion	Vs	0	400	0	100 == 1.00
0x3C	60	R/W	C1.19	T-Portion for DT1	S	0	1000	0	100 == 1.00
0x3D	61	R/W	C1.20	Gain ( C1.13 and C1.16)	V/V	1	32	1	2 = Factor 2.00
0x3E	62	R/W	C1.21	Comparator upper level	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0x3F	63	R/W	C1.22	Comparator lower level	V	-9999	9999	0	
0x40	64	R/W	C1.23	Comparator delay into window	S	0	9999	0	1 == 10 ms
0x41	65	R/W	C1.24	Comparator delay out of window	S	0	9999	0	0 == no delay
0x42	66	R/W	C1.25	Comparator selection COMP_1	---	0	3	0	0 = off 1 = Set value 2 = Actual value 3 =Lag error
0x43	67	R/W	C1.26	Cable fracture detection feedback	---	0	1	0	0 = off; 1 = active
0x44	68	R/W	C2.00	Controller selection	---	0	4	0	0 = off 1 = P-PT1-I-DT1 2 =Remote 3 =dff 4 =Remote + dff
0x45	69	R/W	C2.01	Safety function	---	0	1	0	0 = off; 1 = on
0x46	70	R/W	C2.02	Linearization	---	0	6	0	0 = linear 1 ... 5 = standard curves 6 = customized curve
0x47	71	R/W	C2.03	Gain A	V/V	0	200	100	100 == Factor 1.00
0x48	72	R/W	C2.04	Gain B	V/V	0	200	100	100 == Factor 1.00
0x49	73	R/W	C2.05	Set value sign and gain	V/V	-400	400	100	100 == Factor 1.00 Sign and gain!
0x4A	74	R/W	C2.06	Set value offset	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0x4B	75	R/W	C2.07	Dead band compensation A	V	0	9999	0	1000 == 1.000 V
0x4C	76	R/W	C2.08	Dead band compensation B	V	0	9999	0	9.999 V = max. current depending on solenoid selection
0x4D	77	R/W	C2.09	Sensor type  Attention: No negative controller output possible when 10, 11 or 12 is selected!	---	0	12	4	off = Deactivated 1 = 0...20mA 2 = 4...20mA 3 = 12mA +-8mA 4 = 0...10V 5 = 0...+-10V 6 = 6V +-2.5V 7 = 7.5V +-2.5V 8 = 6V +-5V

ID <sub>Hex</sub>	ID <sub>dec</sub>	W/R	Na me	Function	Unit	Min	Max	Def	Description
									9 = 7,5 +5V> 10 = 0..20mA (positive contr. outp. only) 11 = 4..20mA (positive contr. outp. only) 12 = 0..10V (positive contr. outp. only) 13 = reserved 14 = 5V+-3.0V 15..27 = reserved 28 = 5V+-2.6V
0x4E	78	R/W	C2.10	Actual value gain	V/V	0	400	100	100 == Factor 1.00
0x4F	79	R/W	C2.11	Actual value offset	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0x50	80	R/W	C2.12	Actual value sign	---	- 1	+ 1	1	- 1 = negative 0 = off + 1 = positive
0x51	81	R/W	C2.13	P-Portion Kp <sub>1</sub>	V/V	0	400	0	100 == Factor 1.00
0x52	82	R/W	C2.14	T-Portion for PT1 (to C1.16)	S	0	1000	0	100 == 1.00
0x53	83	R/W	C2.15	Threshold (C1.13, C1.16)	V	0	9999	9999	1000 == 1.000 V
0x54	84	R/W	C2.16	P-Portion Kp <sub>2</sub>	V/V	0	400	0	100 == Factor 1.00
0x55	85	R/W	C2.17	I-Portion	V/s	0	4000	0	1000 == 1.000
0x56	86	R/W	C2.18	D-Portion	Vs	0	400	0	100 == 1.00
0x57	87	R/W	C2.19	T-Portion for DT1	S	0	1000	0	100 == 1.00
0x58	88	R/W	C2.20	Gain (C1.13 and C1.16)	V/V	1	32	1	2 = Factor 2.00
0x59	89	R/W	C2.21	Comparator upper level	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0x5A	90	R/W	C2.22	Comparator lower level	V	-9999	9999	0	
0x5B	91	R/W	C2.23	Comparator delay into window	S	0	9999	0	1 == 10 ms
0x5C	92	R/W	C2.24	Comparator delay out of window	S	0	9999	0	0 == no delay
0x5D	93	R/W	C2.25	Comparator selection COMP_2	---	0	3	0	0 = off 1 = Set value 2 = Actual value 3 = Lag error
0x5E	94	R/W	C2.26	Cable fracture detection feedback	---	0	1	0	0 = off; 1 = active
0x5F	95	R	E00	Operation mode (depends on HW + SW version)	---	1	11	3	1 = Open loop one valve 2 = Open loop two valves 3 = Closed loop one valve 4 = Closed loop on application 6 = Closed loop valve/application 8 = Closed loop application/ application 10 = Controller function only, one feedback 11 = Controller function only, two feedback
0x60	96	R/W	E01	Analogue output (depends on HW + SW version)	---	1 and 14	13 and 21	1	1 = d1.01 to 13 = d1.13 and 14 = d2.01 to 21 = d2.13
0x61	97	R/W	E02	Push-Pull function (depends on HW + SW version)	---	0	1	0	0 = off v(no push pull) 1 = active 2 = common "+" for solenoids (Remark: only for max 0,8 A current ) 3 = full bridge 4 = off + detection low current to solenoid 5 = active + detection low current to solenoid
0x62	98	R/W	E03 E1.03	Solenoid selection Solenoid selection A (depends on HW + SW version)	---	1	7	6	Standard solenoid definition 1 = 0,8 A 2 = 1,1 A 3 = 1,3 A 4 = 1,6 A 5 = 2,4 A 6 = 2,7 A 7 = 3,5 A (depends on HW + SW version)
0x63	99	R	E04 E1.04	P-Portion current contr. Energization A	---	500	9999	500	Default for 2,700 A solenoid
0x64	100	R	E05 E1.05	I-Portion current contr. Energization A	---	500	9999	500	
0x65	101	R	E06 E1.06	P-Portion cur. contr. de- energization A	---	1300	9999	1300	
0x66	102	R	E076 E1.07	I-Portion cur. contr. De- energization A	---	500	9999	500	
0x67	103	R/W	E08	Ramp selection	---	1	2	1	0 = digital set v. (time constant) 1 = all set v. (rise constant.) 2 = selectable ramps
0x68	104	R/W	E09	Time delay enable signal	s	0	9999	0	1000 = 1.00s

ID <sub>Hex</sub>	ID <sub>dec</sub>	W/R	Name	Function	Unit	Min	Max	Def	Description
0x69	105	R/W	E10 E1.10	Solenoid current adaptation A	---	50	110	100	Variable adjustment of max. current 100 == Factor 1.00
0x6A	106	R/W	E11	Initial current solenoid A	V	0	9999	0	3.000 V = 30 % of max. rated current
0x6B	107	R/W	E12	Initial current solenoid B	V	0	9999	0	
0x6C	108	R/W	E13 E1.13	Dither Amplitude A	V	0	3000	0	
0x6D	109	R/W	E14 E1.14	Dither Frequency A	Hz	1	300	0	---
0x6E	110	R/W	E15	Selection set point S1.06 (U/I)	---	0	11	1	off = Deactivated 1 = Voltage -10V..+10V 2 = Voltage 0..10V 3 = Voltage 5V+-5V 4 = Voltage 5V+-4.5V w/o signal observation 5 = Voltage 5V+-4.5V with signal observation 6 = 0..20mA w/o cable fract. det. 7 = 10+-10mA w/o cable fract. det. 8 = 4..20mA w/o cable fract. det. 9 = 4..20mA with cable fract. det. 10 = 12+-8mA w/o cable fract. det. 11 = 12+-8mA with cable fract. det.
0x6F	111	R/W	E16	Reserved	---	---	---	---	---
0x70	112	R/W	E17	Set value activation mode	---	0	3	off	off = 4 digital, 3 analog active 1 = 5 digital SP, 3 analog active 2 = only 4 digital active 3 = only 5 digital active
0x71	113	R/W	E18	Error / Comparator output selection Modus 1,2	---	off	1	off	off = break off 1 = break on
				Modus 3,4,10,11	---	off	5	off	off = break off, comp. positive logic 1 = break on, comp. positive logic 2 = break follows comp. positive logic 3 = break not and comp. positive logic 4 = break and comp. negative logic 5 = break not and comp neg. logic
				Modus 6,8	---	off	13	off	off = break off, comp. positive logic 1 = break on (supply) comp. pos. log 2 = break follows comp., comp. pos. log 3 = break log. not comp., comp. pos. log 4 = break log. not comp., comp. neg. log 5 = break a. comp. same, comp. neg. l. 6 = break follow Comp1, comp. pos. log 7 = break log. not Comp1, comp. pos. l. 8 = break log. not Comp1, comp. neg. l. 9 = break a. Comp1 same, comp. neg. l. 10 = break follow Comp2; comp. pos. l. 11 = break log. not Comp2, comp. pos. l. 12 = break log. not Comp2; comp. neg. l. 13 = break a. Comp2 same, comp. neg. l.
0x72	114	R/W	E19	Factor for analog output (depends on HW + SW version)	V/V	-400	400	100	100 == Factor 1.00 Sign and gain!
0x73	115	X	E20	Reserved	---	---	---	---	
..	..								
0xA2	162	X	---	Reserved	---	---	---	---	
0xA3	163	R/W	E 22	Profinet Slave Address	---	0	32	0	0 = No bus function 1 = Standard Profinet 2..5 = Multiple Slave Profinet
0xA4	164	R/W	C1.27	Hysteresis command A	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0xA5	165	R/W	C2.27	Hysteresis command B	1	-9999	9999	0	
0xA6	166	X	---	Reserved	---	---	---	---	
0xA7	167	X	---	Reserved	---	---	---	---	
0xA8	168	X	---	Reserved	---	---	---	---	
0xA9	169	X	---	Reserved	---	---	---	---	
0xAA	170	X	---	Reserved	---	---	---	---	
0xAB	171	X	---	Reserved	---	---	---	---	
0xAC	172	X	---	Reserved	---	---	---	---	
0xAD	173	X	---	Reserved	---	---	---	---	
0xAE	174	X	---	Reserved	---	---	---	---	
0xAF	175	X	---	Reserved	---	---	---	---	



ID <sub>Hex</sub>	ID <sub>dec</sub>	W/R	Name	Function	Unit	Min	Max	Def	Description
0xB0	176	R/W	E Int	Internal Digital Switches (Read/Set)	---	0	0xFFFF		0x0001 = Din_1 active (Read/Write) 0x0002 = Dout_1 active (Read only) 0x0004 = Comp_1 active (Read only) 0x0008 = reserved 0x0010 = Din_2 active (Read/Write) 0x0020 = Dout_2 active (Read only) 0x0040 = Comp_2 active (Read only) 0x0080 = reserved 0x0100 = Input SP1 active (Read only) 0x0200 = Input SP2 active (Read only) 0x0400 = Enable active (Read only) 0x0800 = Error active (Read only) 0x1000 = Input SP3 active (Read only) 0x2000 = Input SP4 active (Read only) 0x8000 = Bus Disable Card (Read/Write)
0xB1	177	R/W	E 23	Profinet telegram timeout window	S	0	9999	0	0 == function deactivated 1 == 10 ms
0xB2	178	R/W	E 26	Profinet Timeout Error handling	---	0	1	0	0 = Blinking Enable Led shows Profinet timeout 1 = Profinet timeout causes error.
0xB3	179	R/W	C1.33	I-portion limitation	V	0	9999		0 == 0.000 V; 9999 == 9.999 V
0xB4	180	R/W	C2.33	I-portion limitation	V	0	9999		0 == 0.000 V; 9999 == 9.999 V
..	..								
0xD2	210	R/W	E 31	Mode of the analog output	---	1	2	2	1 = Voltage output at pin 10b 2 = Current output at pin 10b.
0xD3	211	R/W	E 32	Selection set point S1.07 (U/I)	---	0	11	1	off = Deactivated 1 = Voltage -10V...+10V 2 = Voltage 0...10V 3 = Voltage 5V+-5V 4 = Voltage 5V+-4.5V w/o signal observation 5 = Voltage 5V+-4.5V with signal observation 6 = 0...20mA w/o cable fract. det. 7 = 10+-10mA w/o cable fract. det. 8 = 4...20mA w/o cable fract. det. 9 = 4...20mA with cable fract. det. 10 = 12+-8mA w/o cable fract. det. 11 = 12+-8mA with cable fract. det.
0xD4	212	R/W	E 33	Offset for analog voltage output (depends on HW + SW version)	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
0xD5	213	R/W	E 34	Offset for analog current output (depends on HW + SW version)	mA	-9999	9999	0	-1000 == -1.000 mA; 1000 == 1.000 mA
..	..								
0xDA	218	R/W	C1.36	Sensor signal correction factor for signal < 0. branch 1	V/V	-100	100	100	100 == Factor 1.00
0xDB	219	R/W	C2.36	Sensor signal correction factor for signal < 0. branch 2	V/V	-100	100	100	100 == Factor 1.00
0xDC	220	R/W	C1.37	Spool overlap compensation A	V	0	9999	0	1000 == 1.000 V
0xDD	221	R/W	C1.38	Spool overlap compensation B	V	0	9999	0	9.999 V = max. current depending on solenoid selection
0xDE	222	R/W	C2.37	Spool overlap compensation A	V	0	9999	0	1000 == 1.000 V
0xDF	223	R/W	C2.38	Spool overlap compensation B	V	0	9999	0	9.999 V = max. current depending on solenoid selection
..	..								
0xE5	229	X	E sta	Reserved	---	---	---	---	
0xB6	182	R/W	E 35	Factor analog output current	---	-200	200	100	100 == Factor 1.00
..	..								
0xD4	212	R/W	E 33	Offset for analog output (depends on HW + SW version)	V	-9999	9999	0	-1000 == -1.000 V; 1000 == 1.000 V
..	..								
0xDA	218	R/W	C1.36	Sensor signal correction factor for signal < 0. branch 1	V/V	-100	100	100	100 == Factor 1.00
0xDB	219	R/W	C2.36	Sensor signal correction factor for signal < 0. branch 2	V/V	-100	100	100	100 == Factor 1.00
0xDC	220	R/W	C1.37	Spool overlap compensation A	V	0	9999	0	1000 == 1.000 V
0xDD	221	R/W	C1.38	Spool overlap compensation B	V	0	9999	0	9.999 V = max. current depending on solenoid selection
0xDE	222	R/W	C2.37	Spool overlap compensation A	V	0	9999	0	1000 == 1.000 V
0xDF	223	R/W	C2.38	Spool overlap compensation B	V	0	9999	0	9.999 V = max. current depending on solenoid selection
..	..								
0xE6	230	R/W	L1.x0	Linearization curve branch 1 [0,0]	V	0	0	0	1000 == 1.000 V
0xE7	232	R/W	L1.y0	Linearization curve [0,0]	V	0	9999	0	

ID <sub>Hex</sub>	ID <sub>dec</sub>	W/R	Name	Function	Unit	Min	Max	Def	Description
0xE8	232	R/W	L1.x1	Linearization curve [1,1]	V	0	9999	1250	
0xE9	233	R/W	L1.y1	Linearization curve [1,1]	V	0	9999	1250	
0xEA	234	R/W	L1.x2	Linearization curve [2,2]	V	0	9999	2500	
0xEB	235	R/W	L1.y2	Linearization curve [2,2]	V	0	9999	2500	
0xEC	236	R/W	L1.x3	Linearization curve [3,3]	V	0	9999	3750	
0xED	237	R/W	L1.y3	Linearization curve [3,3]	V	0	9999	3750	
0xEE	238	R/W	L1.x4	Linearization curve [4,4]	V	0	9999	5000	
0xEF	239	R/W	L1.y4	Linearization curve [4,4]	V	0	9999	5000	
0xF0	240	R/W	L1.x5	Linearization curve [5,5]	V	0	9999	6250	
0xF1	241	R/W	L1.y5	Linearization curve [5,5]	V	0	9999	6250	
0xF2	242	R/W	L1.x6	Linearization curve [6,6]	V	0	9999	7500	
0xF3	243	R/W	L1.y6	Linearization curve [6,6]	V	0	9999	7500	
0xF4	244	R/W	L1.x7	Linearization curve [7,7]	V	0	9999	8750	
0xF5	245	R/W	L1.y7	Linearization curve [7,7]	V	0	9999	8750	
0xF6	246	R/W	L1.x8	Linearization curve [8,8]	V	0	9999	9999	
0xF7	247	R/W	L1.y8	Linearization curve [8,8]	V	9999	9999	9999	
0xF8	248	R/W	L2.x0	Linearization curve branch 2 [0,0]	V	0	0	0	1000 == 1.000 V
0xF9	249	R/W	L2.y0	Linearization curve [0,0]	V	0	9999	0	
0xFA	250	R/W	L2.x1	Linearization curve [1,1]	V	0	9999	1250	
0xFB	251	R/W	L2.y1	Linearization curve [1,1]	V	0	9999	1250	
0xFC	252	R/W	L2.x2	Linearization curve [2,2]	V	0	9999	2500	
0xFD	253	R/W	L2.y2	Linearization curve [2,2]	V	0	9999	2500	
0xFE	254	R/W	L2.x3	Linearization curve [3,3]	V	0	9999	3750	
0xFF	255	R/W	L2.y3	Linearization curve [3,3]	V	0	9999	3750	
0x100	256	R/W	L2.x4	Linearization curve [4,4]	V	0	9999	5000	
0x101	257	R/W	L2.y4	Linearization curve [4,4]	V	0	9999	5000	
0x102	258	R/W	L2.x5	Linearization curve [5,5]	V	0	9999	6250	
0x103	259	R/W	L2.y5	Linearization curve [5,5]	V	0	9999	6250	
0x104	260	R/W	L2.x6	Linearization curve [6,6]	V	0	9999	7500	
0x105	261	R/W	L2.y6	Linearization curve [6,6]	V	0	9999	7500	
0x106	262	R/W	L2.x7	Linearization curve [7,7]	V	0	9999	8750	
0x107	263	R/W	L2.y7	Linearization curve [7,7]	V	0	9999	8750	
0x108	264	R/W	L2.x8	Linearization curve [8,8]	V	0	9999	9999	
0x109	265	R/W	L2.y8	Linearization curve [8,8]	V	9999	9999	9999	
..	..								

Table 11: Parameter list

**12 Declaration of Conformity****EC Declaration of Conformity in accordance with  
EMC Directive 2014/30/EU**

HCS Hydraulic Control Systems GmbH  
Neuffener Str. 29  
D-72636 Frickenhausen

Hereby declares that the product described as follows complies in terms of its design, as well as in the version placed in the stream of commerce by us, with the relevant requirements of the directive. This declaration is void in the event of any change to the product without our written agreement.


Product:	Digital Amplifier and Controller Card
Intended use	Automation systems (industrial applications)
Model:	<b><u>DAC-4x(A)-x</u></b>
Rated voltage:	24 V DC; SELV, PELV
Rated power:	max. 100 VA
Protection class:	III
Protection degree:	IP00 (IP20 on request)
Relevant EU Directive:	EMC Directive 2014/30/EU
Applicable EU Standards:	
Emissions:	EN 61000-6-4:2007 + A1:2011; EN 61000-6-3:2007 + A1:2011
Immunity:	EN 61000-6-2: 2019
Date/manufacturers signature	
15.01.2024	
Details of signatory:	Dipl.-Ing. (FH) Peter Deuschle (General Manager)

Figure 26 : Declaration of conformity

- End -